Assembly instruction

INTRODUCTION

Thank you for purchasing our products. Please read the instructions carefully before installation and keep it in a safe place for future reference. If you need any assistance or support, please feel free to contact our customer support team.

PRECAUTIONS

1. There are many components and accessories in the package. Each component and accessory is labeled with a letter or a number, check carefully before using any of them. Keep them away from children to prevent accidents.

2. Please install the product on a clean and soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.

3. The main components of the product are relatively heavy. Please pay attention to safety during installation.

4. The product is not stable during installation. Please do not move it randomly before it is completely installed.


5. This product requires two people to install.












6. if you have any questions during installation, please contact the customer service in time.

* PLEASE BE SURE TO FOLLOW THE INSTALLATION STEPS IN THE MANUAL TO AVOID UNNECESSARY LOSSES CAUSED BY IMPROPER INSTALLATION.





















* IF YOU NEED FURTHER ASSISTANCE, PLEASE CONTACT THE CUSTOMER SERVICE ONLINE.


HARDWARE LIST



A  3.5x25 32 PCS	B  62 PCS	C  62 PCS	D  8 PCS	E  8x30 4 PCS
F  3 SETS	G  4 PCS	H  5*75mm 4 PCS	I  3.5x12 52 PCS	J  1 PC
K  4 PCS	L  L=1116mm 1 PC	M  M6 3 PCS	N  1 PC	O  3 PCS
P  4 PCS	Q  3.5x16 8 PCS	R  M6x45 3 PCS		

PARTS LIST

1  1PC	2  1PC	3  1PC	4  2PCS	5  1PC
6  1PC	7  1PC	8  1PC	9  4PCS	10  1PC
11  2PCS	12  3PCS	13  3PCS	14  2PCS	15  2PCS
16  4PCS	17  2PCS	18  1PC	19  2PCS	20  1PC
21  2PCS	22  1PC	23  1PC	24  1PC	



6
4
4
5
2
9
11
8
9
9
9
7
11
1
10
3
24
18
13
20
12
22
23
16
16
15
14
13
17
19
12
21
X2

STEP 1


INSTALLATION STEPS


Press the plastic part in the indicated direction to separate drawer runner F1 and F2 before assembling.

REMARK:
Please grip the F1 part while sliding the F2 part




STEP 2







F1x3PCS	Ix9PCS


STEP3









STEP4






STEP5




Cx8PCS


STEP6




Cx8PCS


STEP7



B
B
B
B
B
B
B
B
B
B
B
B
B
B
B
6
5
3



Bx14PCS


STEP8


B
B
8
7
E
C
E
3
C





Bx2PCS


Cx6PCS



Ex4PCS

STEP9




Cx4PCS

STEP10




Cx4PCS

STEP11




	Ax4PCS
	Cx2PCS

STEP12




	Bx18PCS

STEP13




Cx9PCS


STEP14




Cx9PCS


STEP15







STEP16









STEP17



x2




x2



Ax24PCS

STEP18




x2

x2


Cx8PCS

STEP19




	Ax4PCS

STEP20




	Cx4PCS

STEP21




Ix12PCS

STEP22





Ix6PCS

STEP23




STEP24






STEP25




	Ix8PCS

STEP 26



	Lx1PC
	Ox3PCS
	Rx3PCS
	Mx3PCS
	Nx1PC


STEP27





Ix8PCS


Kx4PCS

STEP28




STEP29




	Px4PCS
	Qx8PCS

STEP30



	Gx4PCS

STEP31



	Hx4PCS

STEP32

