



Installation Steps:

Thank you for using our products. Please read the operation manual before installation. Please keep this operation manual as a reference. Installation by a professional electrician is recommended.

1. Install the iron pipe above the light body in order, then hang the ceiling square box on the iron pipe.
2. Fix the hanging plate on the mounting box.
3. Connect the black wire (L) to the fire wire and the white wire (N) to the zero wire with wire caps and wrap tightly with insulating tape. Connect the ground wire of the light to the ground wire of the junction box. If the house does not have a ground wire, connect it to the green screw on the wall plate. (Screw labeled: GND). Carefully tuck all wires into the junction box.
4. Secure the bulb to the wall plate with the round head nut.
5. Fit the bulb into the head, ensuring good contact.

Attention:

1. The input power of the lamp is AC 120V 50Hz.
2. Any behavior that violates residential fire protection regulations is prohibited.
3. Under no circumstances should the lamps be covered with heat insulation pads or wooden materials.
4. Before maintenance, make sure that the power supply of the lamp has been cut off and the light source has cooled down. Before powering on, make sure that the light source and the lamp holder are connected correctly.
5. Please wipe with a towel or flannel, and clean the lamp body with a non-corrosive detergent. Do not scrub directly, wipe with water or a damp cloth.
6. If you have any questions about this manual, please consult a qualified lighting installation engineer.