

































ASSEMBLY INSTRUCTION

			AX1PC	BX1PC	CX1PC
					
			DX1PC	EX1PC	FX1PC
					
GX1PC	HX3PCS	IX3PCS	JX1PC	KX4PCS	
					
① x 12	② x 12	③ x 24	④ x 4	⑤ x 4	⑥ x 21
					
⑦ x 4	⑧ x 4	⑨ x 1	⑩ x 1	⑪ x 6	⑫ x 6
					


1**2****3****4**

5**6****7****H****8**


!! Notice! !
Place top panel on the unit loosely,
do not tighten the fixings until step10




9




10




11




12




13




14




15




16



17



18



Warning: DO NOT sit or stand on the bookcase as this may damage the product and cause serious bodily injury.