








Console Table










ASSEMBLY INSTRUCTION




											
x20		x20		x8		x36		x20		x4	
A	M6x35mm	B	Ø15mm	C	8x30mm	D	M5*38mm	E	M6*25mm	F	M5*25mm

ASSEMBLY INSTRUCTION


 ① x1	 ② x2	 ③ x2	 ④ x2
 ⑤ x2	 ⑥ x2	 ⑦ x2	 ⑧ x6

INSTALLATION INSTRUCTION



Matters needing attention



Be sure to use the proper screws to avoid damaging the parts



Wrong screws can cause the plank to crack




The right screw is the right size

ASSEMBLY INSTRUCTION


Matters needing attention

- (1) When installing the screws in the installation step, the screws do not need to be tightened.
After this installation step is confirmed and the holes are aligned, then tighten all the screws.
- (2) If the screws are tightened during the installation process, it will cause problems such as misalignment of the screw holes and misalignment of the board in subsequent installations.




INSTALLATION INSTRUCTION

STEP 1




STEP 2




INSTALLATION INSTRUCTION

STEP 3





X2



DX12




STEP 4





DX4

INSTALLATION INSTRUCTION

STEP 5






STEP 6






INSTALLATION INSTRUCTION

STEP 7





STEP 8





INSTALLATION INSTRUCTION

STEP 9




STEP 10




INSTALLATION INSTRUCTION

STEP 11



STEP 12



INSTALLATION INSTRUCTION

STEP 13

