















**PARTS LIST**

	A. 1PC
	B. 1PC
	C. 1PC
	D. 1PC
	E. 4PCS
	F. 5PCS
	G. 2PCS
	H. 2PCS
	I. 4PCS
	J. 4PCS
	K. 1PC



**ASSEMBLY INSTRUCTION**



**NOTE:** Insert 'G' on the legs with ↑ and 'H' on the legs without ↑.

**NOTE:** Arrow indicates front of seat.

**NOTE:** The ↑ must be facing the seat's front.



**Thank you for purchasing our product!**

Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days.

**We appreciate your business!**