Fix the turned Leg to the corner of the apron with the Flat Washer Spring Washer And Hex Nut

using the Spanner to tighten it.

Remove the plastic cover from the Pedestal and Footings. Thank You for purchasing this Quality product. It has been engineered for easy assembly yet constructed for durability. Please take the time to read and follow the instruction while assembling.

01


(02)

ASSEMBLY INSTRUCTION


Butterfly Dining Table

36" x 48" x 60"L x (1- 12"Leaf) x 29 5/8"H


1 Turn the under side of the Table Top over and place it on a clean and smooth surface such as rug or carpet to avoid the Table Top from being scratched.



Turn the assembled Table over carefully pull the Table Top to both two sides then lift up the Center Leaf from the compartment and turn the Center Leaf to open to lie on apron.



Push the side Center Top at both end close to the Table Leaf until it leaves no empty spaces.







3 Repeat the same step for the other three Legs .

List of Part For 1 Set

01)	110	Table Top	1
02	Post and	Table Leg With Nail Leg	4

List of hardware For 1 Set

(a)	0	Flat Washer	8
b	0	Spring Washer	8
C		Hexagon Nut	8
d	5	Spanner 12.8mm	1

/ Important Notes

- *Keep all hardware parts out of reach of children.
- * Must tighten screws periodically. With use screws will become loose. Check tightness of all screws every 6-8 weeks.
- Don't attempt to repair or modify parts that are broken or defective.
 Please contact the store immediatedly.
- Do not tighten all screw / bolt until all completely assembled.

Notes

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials including staples & packing straps before you start to assemble.

PAGE 1 OF 1