


















① x1 	② x1 	③ x1 	④ x1 	⑤ x1 	
⑥ x1 	⑦ x1 	⑧ x1 	⑨ x1 	⑩ x2 	
A x2  M6	B x10  M6*30	C x24  M6*10	D x4 	E x1  EL ER	F x4 
G x4 	H x1 	I x18 	J x16  M6*25	K x1  Tool	


1




2




3




4




5




6




7




8



9




10



Tip: If it is difficult to open and close the door after installation, loosen or tighten the screws of the hinge

11



12

