


Assembly Instructions



ITEM	DESCRIPTION	QUANTITY
A	Snowman Head	1
B	Snowman Front Body	1
C	Snowman Back Body	1
D	Snowman Front Bottom	1
E	Snowman Back Bottom	1
F	Carrot Nose	1
G	Scarf	1
H	Snowman Hands	2
I	Cardinals	2
J	Ground Stakes	4
K	Zip Ties	14

1. Diagram of Parts

Remove all components from the box and lay flat on the floor.

2. Assembling the Snowman Body

Lay the Snowman Front Body (B) on top of the Snowman Back Body (C) and fasten with Zip Ties (K) on both sides. Lay the Snowman Front Bottom (D) on top of the Snowman Back Bottom (E) and fasten with Zip Ties (K) on both sides.

3. Assembling the Snowman Head, Body, and the Bottom

Lay the Snowman Body (B+C) on top of the Snowman Bottom (D+E) and fasten with Zip Ties (K) on the sides. Lay the Snowman Head (A) on top of the Snowman Body (B+C) and fasten with Zip Ties (K) on the sides.

4. Attaching the Accessories and Securing the Snowman to the Ground

Insert the connecting rod on the bottom of the Snowman Hands (F) into the sides of the Snowman Front Body (B). Attach the Carrot Nose (F) and the Cardinals (I) onto the Snowman Head (A) and the Snowman Hands (H). Place the Ground Stakes (J) over the holes, two on the front and two at the back, then into the ground. Surround the Snowman neck with the Scarf (E).



WARNING: Risk of fire, personal injury and electric shock.

1. Make sure light set is not connected to power before starting.
2. Keep wires clear of being pinched or cut during assembly, installation or use. Discard product with cut wire insulation.
3. Do not press or grasp bulbs during assembly or installation.
4. Watch for bulbs that may have broken if parts shifted in transit.
5. This product is not a toy; for adult use only. It should not be played with or placed where children can reach it.

6. Make sure stakes are clear of underground sprinkler, telephone, and power lines before starting.

7. Please read all instructions and warnings included with this product before using.

If lights do not work:

- a. Make sure there is power to the outlet and the product is plugged in.
- b. Make sure the cord is well connected to the adapter.
- c. If plugged into a GFCI outlet or GFCI-protected circuit, check the rest of the GFCI to make sure it did not trip. Discard product if GFCI repeatedly trips.