



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.



A C A C I A

VERVE

Dining Table MEDIUM

► IMPORTANT INFORMATION

Under normal use, ACACIA Dining Table will last for years. It is, however, important to follow basic care tips to prolong the life of your table.

USE & CARE

Your table does not require special waxing or oiling. You may dust at any time with a clean, dry, soft cloth. If deeper cleaning is necessary, use a damp, non-abrasive cloth and a solution of cool water and mild detergent, immediately wipe dry.

Moisture and heat can damage the wood finish. To prevent moisture damage, promptly wipe up any spills or any other moisture. To prevent heat damage, avoid placing your table too close to heat sources such as stovetops, ovens, HVAC vents and radiators.

Wood may expand and contract with seasonal humidity changes. Maintaining consistent humidity levels will minimize movement in the wood and help prevent warping.

Over time, air and sunlight may change the color of natural wood. To prevent fading, avoid placing your table in direct sunlight.

Avoid dragging sharp or rough objects across the surface of your wood table, or it will become scratched.

Ensure that your table legs are securely attached regularly.

Any modification or failure to follow the recommended care will void the product warranty.

