

Use & Care

CLEANING INSTRUCTIONS

- Clean using a soft cloth or sponge dampened with mild warm soapy water
- Dry with a soft, clean cloth
- Dust regularly with dry dust cloth or feather duster, gently wiping over the surface
- If needed, use soft-bristled brush (such as a toothbrush) for joints or crevices
- Avoid contact with abrasive substances, such as steel-bristle brushes, alkaline, or similar products or scrubbers
- Unsightly mold accumulation? No worries, this can be cleaned using the same steps above. Use your mild soapy solution, a sponge or soft-bristled brush to remove it, apply slight pressure, if necessary. After cleaning, always dry with soft, clean cloth.

USING YOUR NEW ECCOSTYLE BAMBOO PRODUCT

Keep in mind although your bamboo furniture may be resistant to water and bacterial build-up, it is not waterproof. Proper care and cleaning are still necessary (see above cleaning instructions).

DID YOU KNOW

- With a growth rate of merely 5 years, bamboo has the fastest growth cycle of any renewable furniture material. By comparison, pine and rubberwood take 12-25 years to mature
- Laminated bamboo boards have the lowest moisture expansion/contraction displacement ratio of any natural home furnishings resource making it 50% less than oak or pine, giving bamboo furniture long term stability in all climates
- Although referred to as wood, bamboo is the largest member of the grass family