


Use instruction



NOTE:
1: This lighting only can be used in a room.
2: Do not turn the switch on before assembly.
3: If you want to change a bulb, please turn the switch off, and after the bulb is cold.
Voltage: 110V
Bulb: E26

▲ line up the hole for hot air to escape