



Comfortable dining experience  
Bringing aesthetics to life

**MADE IN CHINA**

# BOUCLE FABRIC DINING CHAIR

User Manual





**SIZE:** 21.2\*22\*33.5INCH

**N. W. :**13LBS

### **⚠ WARNING**

-Assembly: Adult assembly required.

**CHOKING HAZARD:** Small screws and parts can pose a choking risk. Keep them away from children under 3 years old.

-Packaging: Keep these packaging materials out of reach of children.












-Inspection: check the product for wear and tear, and any part is damaged, missing, or has loose screws. Check all fasteners regularly.

-Weight Limit: 330 lbs (150 kg).


-Safety: Keep away from heat sources.

-Storage: Do not leave outdoors or near wet surroundings.


## PARTS INVENTORY

<p>A1</p>  <p>X1</p>	<p>A2</p>  <p>X1</p>	<p>L</p>  <p>X1</p>
<p>R</p>  <p>X1</p>	<p>C</p>  <p>X1</p>	<p>D</p>  <p>X1</p>
<p>F</p>  <p>6x40mm</p> <p>X10</p>	<p>G</p>  <p>6x50mm</p> <p>X2</p>	<p>H</p>  <p>X12</p>
<p>I</p>  <p>X4</p>	<p>J</p>  <p>X1</p>	


## INSTALLATION




When installing the backrest, do not tighten the screws yet. Once the screws are all in place, tighten them again.




Align the notches of the chair legs (A1+A2) and install them together




Align L and R with the convex sleeves of A1 and A2, put them on and tighten them with screws F&H from bottom to top.



Put C on and tighten them with screws F&H from bottom to top. When installing the seat cushion, do not tighten the screws first. Tighten them again after the screws are all positioned.



Adjust the foot pegs at the bottom to balance the chair.



Installation complete, please use your chair.

## WARRANTY

metal furniture are generally more durable than plastic ones, but they can sometimes break. While metal furniture can last many years with proper care, products are not guaranteed against damage due to play and use.

Products sold are guaranteed against defects in materials and workmanship for twelve (12) months from the date of original purchase. This warranty is valid only under normal use and for the intended purpose of the product.