


Assembly Instructions



Model No. ZL-ZY0037/ZL-ZY0045/ZL-ZY0046

Contact Us

We're here to help you.






Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

Email: support@epecoya.com

Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.







We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.

AVOID SCRATCHES

In order to avoid scratching, this furniture should be assembled on a soft surface, such as a rug.
























⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.




Parts List

			
① 1pc	② 1pc	③ 1pc	④ 2pcs
			
⑤ 2pcs	⑥ 1pc	⑦ 3pcs	⑧ 1pc



Hardware List

Ax20	Bx20	Cx8	Dx18	Ex1
				
Ø6X43mm	Ø15X12mm	Ø8X30mm	Ø7X47mm	M4X64mm
Fx8	Gx16	Hx8	Ix5	Jx4
				
M6X18mm	4X14mm	Ø18X2mm	M6XØ30mm	20X15X5mm
Kx2				
				
L690mm				



1





2





3





4



5





6




Cx8	Dx10	Ex1
Ø8X30mm	Ø7X47mm	M4X64mm



7






Dx8

Ø7X47mm

8






Gx8	Kx2
	
Ø4X14mm	L690mm



9





10







Fx8	Hx8
	
M6X18mm	Ø18X2mm

12




13





14

STYLE 1





15

STYLE 2



16



OR

