#### WARNING

\*\* WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN \*\*

- \* Switch off the main electrical supply from the main fuse box / circuit breaker before installation.
- \* Inspect item carefully before attempting to install.
- \* If there is any damages or obvious defects, do not install.
- \* Item may not be returned once it has been installed.

### CARE AND MAINTENANCE

\* To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.

\* To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the interior surface of the fixture.

\* Do not use any cleaners with chemical, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

### **NOTICE& IMPORTANT SAFETY INSTRUCTIONS**

\* Please make sure that you have all parts indicated before you begin assembly of this item

\* This item should be assembled on a soft surface to prevent scratching the finish during assembly

\* To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation


\*The external flexible cable or cord of this lamp cannot be replaced

If the cord is damaged, the lamp shall be destroyed

# Part List and Hardware List

| PIECE | DESCRIPTION    | PICTURE                    | QUANTITY   | PIECE | DESCRIPTION  | PICTURE | QUANTITY   |
|-------|----------------|----------------------------|------------|-------|--------------|---------|------------|
| A     | Mounting Plate |                            | 1 <b>X</b> | G     | Nut          | Ē       | 1 <b>X</b> |
| В     | Wire Nut       | <b>E</b> 0                 | 3 <b>X</b> | Н     | Gasket       | ٥       | 1 <b>X</b> |
| С     | Mounting Screw | <b>4</b> 000000 <b>0</b> ∎ | 2 <b>X</b> | I     | Canopy Nut   | Ē       | 2 <b>X</b> |
| D     | Lamp Body      |                            | 1 <b>X</b> | J     | Ground Screw |         | 1 <b>X</b> |
| E     | Shade          |                            | 1 <b>X</b> | К     | Finial       |         | 1 <b>X</b> |
| F     | Cover          | 0                          | 1 <b>X</b> | L     | Bulb         |         | 3 <b>X</b> |


Product Dimensions: 15"L X 15"W X 12"H




### PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 20 minutes.
- \* If you are having difficulty, our friendly Customer Care team is always here to help.

## PLEASUE USE TYPE"B" BULB MAX 40-WATT OR CFL BULB MAX 13-WATT OR LED MAX 9-WATT. THERE ARE 3 X 4W LED BULBS IN THE BOX.







## Step 2: Wire connection

Connect fixture neutral wire (ribbed) to the outlet box neutral wire (usually white) using a wire nut. Connect fixture hot wire (smooth with markings) to the outlet box hot wire (usually black) using a wire nut. CAUTION: Do not reverse the hot and neutral connections

## Grounding Instructions:

Wrap ground wire from outlet box around green ground screw on mounting Plate (A), no less than 2" from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire connector.

