


20X30FT

Quantity	Item	Description
10	A 	Rafter ϕ 38mm
10	B 	Rafter ϕ 38mm
20	C 	Apex and eave pole ϕ 38mm
10	D 	Leg ϕ 38mm
5	E 	Ruggedized tube ϕ 31mm
6		3 way joint
9		4 way joint
4		Base plate
6		Base plate
16		U-shaped nail
22		expansion screws
6		underground anchor
10		3 way joint
20		Peg
108		Bungee
6		Guy lines
1		Roof
2		Wall panel
1		End panel
1		End panel

Note:


- 1) Anchors of this tent is required, you need to anchoring this tent to avoid damage caused by wind, storm or adverse weather
- 2) You need to take this tent apart when the wind speed reach at 10.8m/s
- 3) Please don' t leave the tent up under bad weather conditions
- 4) Polyethylene roof and sidewalls are not fire proof, please be away from sources of fire
- 5)The roof can' t bear heavy loads of standing snow or water. You must clear the standing snow or water in time.



Warning:


1. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and use.
2. Some parts may contain sharp edges, wear protective gloves if necessary. At least four or more people are recommended for safe assembly.
3. Keep all children and pets away from assembly area.
4. Begin assembly not less than 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry line or electrical wires.
5. Install on level ground. This gazebo cannot be permanently staked or attached to concrete floor or platform. The provided stakes are for soft ground use only. If assembling on a hard surface like a deck or concrete, other forms of attachment must be used such as expansion bolts that can be purchased locally.
6. This gazebo is intended for decorative and sunshade purposes only and is not meant to withstand inclement weather including high winds, rain and snow. Gazebo fabric is water resistant, not water proof and may leak during exposure to precipitation.
7. Please lay out all parts before assembling, check out if there is any parts missing or not.
8. KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

Step1:




Step2: Repeat the above steps.

Step3:




Step4: Repeat the above steps.


Step5:




Step6:




Step7:Install The "roof"




Step8:



Step9:



Step10:



Step11:

