










Installation & Assembly







TEIL	NR.	STK.
	1	1 PCS
	2	1 PCS
	3	4 PCS
	4	4 PCS
	5	12 PCS
	6	2 PCS
	7	4 PCS
	8	2 PCS
	9	1 PCS
	10	10 PCS




A) 1 Left Side Panel



B) 1 Right Side Panel




C) 1 Left Back Panel




D) 1 Door


Remove the screws of the left panel and the bottom with a screwdriver.




Lay the tool cabinet flat and pull out the tool chest




Install the tool box handle





Locate the wheel in the tool cabinet drawer and install the wheel.




Assemble the middle space as pictures show:




A
B
C
2


D
A
C
B
2


10

