






# INSTALLATION MANUAL

## FLOOR LAMP



# PACKING LIST


	Rechargeable Lampshade
	4 Connecting Rods
	Base
	USB-A to USB-C Cable

# PRODUCT ATTRIBUTES


Light source power / w	4.5w
Battery capacity / mAh	4000mAh
Usage duration (fully charged state)	7h
Switch position	Top of Lampshade
Switching mode	Touch

# INSTALLATION


## 1. Install the base connecting rod




## 2. Magnetic lampshade




## 3. The lampshade can be tilted



#### 4. Display at different heights



## SWITCH INSTRUCTIONS



Tap to adjust the color temperature, and press and hold to adjust the brightness.