

PADDED PIANO BENCH




Black glossy finish
Storage compartment beneath seat
Solid wood frame and legs
Padded synthetic leather seat
Assembly wrench included at no extra cost

Packing List



Padded Seat X 1
Wood Legs X 4
Hexagon nut X 4
Washer X 4
Wrench X 1

Assembly



- Insert the bolt of the leg into the corner of the bench frame
- Tighten it up with a washer and a nut and make sure the angle is completely aligned
- Assemble the rest of three legs
- The lid will stay open with one hinge