


INSTRUCTION MANUAL

AIR 54





NOTICE


Please retain these instructions for future reference.

- Firmly tighten all bolts, screws, and knobs before use.
- Check all bolts, screws, and knobs every 90 days to ensure they remain secure.
- During assembly, fasten screws loosely at first. Do not fully tighten until the entire unit is assembled.
- Do not use or store this product near open flames or flammable materials.
- Some parts may be heavy or have sharp edges—use caution.
- Moving parts may cause injury, pinching, or cuts—handle with care.
- If any parts are missing, broken, or damaged, discontinue use until repairs or replacements are made.
- Use this product only as described in the instructions. Improper use may void the warranty.

TOOLS REQUIRED



Phillips
Screwdriver



Drill
(recommended)



Two-person assembly
recommended



Estimated assembly
time: 30 minutes


HARDWARE

M6.0 x 65 mm bolt
12 pcs + 1 spare



P1

M4.0 x 60 mm screw
26 pcs + 1 spare



P2

M4.0 x 45 mm screw
34 pcs + 1 spare



P3

M3.5 x 35 mm screw
12 pcs + 1 spare



P4

M3.5 x 30 mm screw
8 pcs + 1 spare



P5

M3.0 x 25 mm screw
2 pcs + 1 spare




P6

M6.0 x 50 mm bolt
4 pcs + 1 spare




P7



PARTS

CARTON 1/2

Wooden house panel- down left
1 pc



B

Wooden house panel- down right
1 pc



B1

Layer
1 pc




H1

Layer
1 pc



I

Layer
1 pc




H2

Platform layer
1 pc




J

Wire panel
1 pc




N

Supporting bars of small platform
2 pcs



K

Supporting bars
4 pcs




L

PARTS

Upper wire panel- left


1 pc



Q

Lower wire panel- left


1 pc



R

Front wire panel- down


1 pc



U

Front wire panel- upper


1 pc



S

Front wire panel- middle

1 pc



T

Shelf panel


1 pc



V

Roof of wooden house


1 pc



X

Wire roof

2 pcs



Y


Hardware bag



PARTS


CARTON 2/2

Wooden house panel- upper & left
1 pc




A1

Wooden house panel- upper & right
1 pc




A2

Wooden house panel- back & upper
1 pc



C

Wooden house panel- back & middle
1 pc



D

Wooden house panel- back & down
1 pc




E

Divider - upper
1 pc



F

Divider- middle
1 pc




G

Layer
2 pcs



H1


Layer
1 pc



I


PARTS

Wire panel
1 pc




P

Upper wire panel- right
1 pc




Q1

Lower wire panel- right
1 pc



R1

Wire panel
1 pc




O

Shelf panel- down area
1 pc



W


Wire panel
1 pc




M

PRODUCT ASSEMBLY

- 01** Connect the wooden house panel, screw the left & right panel A1, A2, B, B1 to the back panel C, D, E by 12XP3.




- 02** Attach the dividers Part F & G to the left and right side of wooden house by 10XP3.




PRODUCT ASSEMBLY

03 Put layer Part H1 in lower position of wooden house, screw layer Part I in lower position of wooden house by 2XP6.




04 Put layers Part H1 and I in middle position of wooden house.




PRODUCT ASSEMBLY

05 Put layers Part H1 and H2 in upper position of wooden house.




06 Attach the supporting bars Part K by 4XP1.




PRODUCT ASSEMBLY

07 Screw the platform layer Part J to supporting bars by 4XP5.




08 Connect the wire panels, screw Part O to Part M and Part N to Part P by 2XP2 each side.




PRODUCT ASSEMBLY

09 Attach the step 08 to wooden house by 4XP2 each side.




10 Attach 2 supporting bars Part L by 4XP1 each side.




PRODUCT ASSEMBLY

11 Screw shelf panel Part V by 4XP5.




12 Connect 2 side wire panels, screw Part Q to Part R and Part Q1 to Part R1 by 2XP2 each side.




PRODUCT ASSEMBLY

13 Attach the step 12 to step 11 by 8XP2.




14 ① Connect the front wire panels, screw Part S, T, U by 2XP2, screw the supporting bars Part L in down area by 4XP1.
② Screw the shelf panel Part W in down area by 4XP5.




PRODUCT ASSEMBLY

15 Screw the front wire panels by 12XP3.




PRODUCT ASSEMBLY

16 Screw the wire roof Part Y by 8XP4.



PRODUCT ASSEMBLY

17 Screw roof Part X to the wooden house by 4XP4.



Finish



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this