









Installation Manual



Heat Press Table




Customer Service: ahomrt@163.com


Parts List

Number	Parts	Quantity
1		1PC
2		2PCS
3		2PCS
4		2PCS
5		1PC
6		1PC
7		1PC
8		1PC
9		1PC
10		1PC
11		4PCS
12		1PC
13		1PC
14		1PC
15		4PCS

Number	Parts	Quantity
A	 M6x35	18PCS
B	 M6x30	6PCS
C	 M4x8	2PCS
D	 M6x20	8PCS
E	 M6x12	12PCS
F	 M8	1PC
G	 M6	6PCS
H		1PC

Step 1


	A x 8
	7 x 1
	8 x 1
	9 x 1
	10 x 1




Step 2

	11 x 4
	F x 1


Tips: Both types of 11 parts are included. Please install according to your needs






Step 3



A x 2


6 x 1



Step 4


	A x 4
	2 x 2




Step 5

 E x 4

 5 x 1




x2





Step 6


	A x 4
	3 x 2




Step 7









Step 8







Step 9

	C x 2
	12 x 1






Step 10



13 x 1












Step 11




14 x 1








Step 12



15 x 4







Final Assembly