

DINING TABLE

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME	15 MINUTES
---------------	------------

B1 (BOX 1)

PARTS IDENTIFICATION


A



TOP

1PC


B



LEAF

1PC

C



TRESTLE BAR

1PC

D




STRETCHER

1PC

B2 (BOX 2)

E



LEG FRAME

2PCS

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:





1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.

Warning!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

HARDWARE IDENTIFICATION

Z-B1 (BOX1) - HARDWARE PACK IS LOCATED IN (B1)


1		BOLT	16PCS
2		FLAT WASHER	16PCS
3		LOCK WASHER	16PCS
4		ALLEN WRENCH	1PC

STEP 1




ASSEMBLY INSTRUCTIONS

STEP 2




STEP 3



ASSEMBLY INSTRUCTIONS

STEP 4



COMPLETE

