

Assembly Manual

1/2

Page 1

Page 2

A(X4)
B(X2)
C(X24)

J(X1)
I(X1)

A(X4)
B(X2)
C(X24)

96pcs
1pcs

96pcs

Assembly Manual

2/2

Page 3

Page 4

Page 5

Page 6

D(X4)

E(X2)

F(X4)
G(X2)
H(X4)