




25 Pre-installation of Door Panel to SL-SR Panel



26 Pre-installation of Door Panel to SL-SR Panel





27

Pre-assemble the door panels with the SL/SR panels.

M6X40
J08*2

M6X25
J06*2

M6X16
J04*4



X2

41



28

Install the rear panel onto the SL/SR panels


G04*1

M6X16
J04*10


M6X25
J06*2



X2




X2



42

29

Back Panel Horizontal Support Reinforcement Installation




F03*2




M6X35
J07*6



M6
J11*6



43




X3

30

Pre-assembly of Roof Hardware Triangular Brackets-x2/3/4/5


G01*4/6/8/10
G02*2/3/4/5
F05*2/3/4/5
H05*4/6/8/10



J09*14/21/28/35
J11*14/21/28/35

Warning: Please install the corresponding quantity of parts based on the size you purchased.

8x6FT-2sets
8x8FT-3sets
8x10FT-4sets
8x12FT-5sets



44


31

Pre-assembly of Roof Hardware Triangular Brackets-x2/3/4/5

F06*4/6/8/10
J13*8/12/16/20

J10*6/9/12/15
J11*6/9/12/15

Warning: Please install the corresponding quantity of parts based on the size you purchased.
8x6FT-2sets
8x8FT-3sets
8x10FT-4sets
8x12FT-5sets




45

32




Installation of Roof Hardware Triangular Brackets

M6X16
J04*4/6/8/10






46

33 Roof Connecting Rod Installation





47


34 C01-C02 Panel Installation



02





48




49

C03 Panel Pre-Installation



Note: Check the number.

Note: Install H11 parts symmetrically.






These clips:
left of number.

These clips:
right of number.

X2

X2

37 C03-C04 Panel Installation






C03: Install with the clips side oriented outward (clips toward SL and SR).
C04: Install at the middle.

51

38 Secure C03-C04 Panel-1



X12



When tightening the inner screws, press down on the corresponding top plate on the outer side of the house.

52