

Assembly Instruction

Aluminum Accent Table

- 1- Tighten Rod On Base
- 2- Then Tighten Top on Rod
- 3- Now Table is ready to use

