


USER MANUAL

Thank you for choosing us.



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps.
- Please contact us when further information and help are needed.

Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings

- Children are not allowed to assemble the product. During assembly, keep all small parts out of the reach of children as they may be fatal if swallowed or inhaled.
- Children are forbidden to climb or play on the product to avoid serious bodily injury caused by the toppling.
- Keep plastic packing bags out of reach of children to avoid any potential danger, such as suffocation.
- We have equipped some high-sized products with anti-dumping accessories. Please fix the product to the wall to prevent personal injury caused by accidental dumping.

Tips-contact us

- If there is any damage after unpacking or you have any questions during assembly, please feel free to contact us at your earliest convenience. Our customer care team provides professional returns or exchanges as well as assembly guidance.


Disassembly Diagram



Part list


Unit: (mm)

①




x1

②




x1

③




x1

④




x1

⑤




x1

⑥




x1

⑦




x1

⑧




x1

⑨



x2

⑩




x2

Components sheet


Unit: (mm)

A Ø6x33mm




x39(+2)

B Ø15x9.5mm




x39(+2)

C Ø8x30mm




x26(+1)

D Ø5/32x12mm




x18

E




x1

F




x1

G Ø3.5x15mm




x2

H Ø3.5x12mm




x12

I Ø4x45mm




x14

J Ø20mm




x39(+2)

K




x1

L




x6

M




x4

Required




2 PERS




Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




1

A  x4
Ø6x33mm




2

A  x8
Ø6x33mm






3

C



x2

Ø8x30mm






4

B





x4

Ø15x9.5mm





5

C  x4
Ø8x30mm



6

B  x8
Ø15x9.5mm





7

A




x7

Ø6x33mm






8

C



x4

Ø8x30mm





9

B




x7


Ø15x9.5mm



10

G  x2
Ø3.5x15mm

F  x1




NOTE: Pass the connector through the slot on the left side panel (3).

NOTE: Place a foam pad under the back panel (6) to prevent unevenness during assembly.

K  x1L  x6H  x12
Ø3.5x12mm

2. Install the fixing pins into the pilot holes to secure the two light strips.

Note: Pass the connector through the slot on the left side panel (3).




1. Peel off the adhesive backing and attach the light strip onto the top panel (1), ensuring the light strip is centered between the two drilled holes for the fixing pins.

3. Install the fixing pins for the control button onto the left side panel (3).



12

C



x8

Ø8x30mm




13

I



x14


Ø4x45mm



14

A  **x8**
Ø6x33mm

 x8
Ø6x33mm




X2

15

B  **x8**
Ø15x9.5mm

 x8
Ø15x9.5mm





16

A




x12

Ø6x33mm





17

C



x8

Ø8x30mm





18

B




x12


Ø15x9.5mm



19




D  x6
Ø5/32x12mm


E  x1




20

D  x12
Ø5/32x12mm





5. Lightly touch the control button to change the light color.



NOTE: Connect the power plug to the outlet for use.



4. Plug the USB connector into the power outlet to operate the light.

M



x4

Peel off the adhesive backing and attach these plastic corner protectors to the four upper corners of the top panel to reduce impact force in case of collision and ensure user safety.



23

J



x39

Ø20mm

Note: After assembly, cover the holes

