


Assembly Instruction

Note:


- 1. Should be assembled on flat ground to keep balance.**
- 2. Before completing the installation, do not tighten the screws.**



It needs at least two people to install.











Before starting the assembly, you must read the whole manual and follow the instructions.














Assembly Instruction

Hardware arts


 Ⓐ M6x12 12pcs	 Ⓑ M6x30 11pcs	 Ⓒ M6x40 4pcs	 M6x20 NUT Ⓓ 10pcs	 Ⓔ M8x15 8pcs	 Ⓕ M8x35 4pcs	 Ⓖ M8x50 2pcs	 4 # Ⓗ 2pc	
---	---	--	---	---	--	--	---	--




Part list


 Ⓛ 1 PC	 Ⓜ 2 PCS	 Ⓝ 1 PC	 Ⓟ 1 PC	 Ⓡ 4 PCS	 Ⓢ 2 PCS
 Ⓣ 4 PCS	 Ⓤ 2 PCS	 Ⓡ 3 PCS	 Ⓟ 8 PCS	 Ⓡ 16 PCS	
					Page 3/7

Assembly Instruction




B		M6x30	9pcs
H			1pc






C		M6x40	4pcs
D		M6x20 NUT	4pcs
H			2pcs




Assembly Instruction

A		M6x12	4pcs
D		M6x20 NUT	4pcs
H			2pcs






F		M8x35	4pcs
H			1pc




Assembly Instruction





E		M8x15	8pcs
H			1pc





A		M6x12	8pcs
H			1pc



Assembly Instruction

B		M6x30	2pcs
D		M6x20 NUT	2pcs
G		M8x50	2pcs
H			2pcs



15		24pcs
----	---	-------

