


# MIRROR CABINET

E152-005-001

V-1-1



Thank you for choosing our products. We are committed to providing excellent customer service and support. Please feel free to reach out to us with any inquiries or assistance you may need.

: [furnitures.service@outlook.com](mailto:furnitures.service@outlook.com)



## WARNING

***To reduce the risk of burns, fire, electric shock, or injury to persons:***

- Disconnect from outlet before putting on or taking off parts.
- Close supervision is necessary when this product is used by, or near children.
- Keep the cord away from heated surfaces.
- Make sure that the electricity is turned off at the power source before proceeding with the installation.
- Always unplug all the power supply cords from before moving the product, testing the product, or repairing the product.
- Do not use outdoors.



## IMPORTANT SAFETY NOTICE READ CAREFULLY BEFORE BEGINNING ASSEMBLY

- Handle the glass with caution! Improperly handling the glass can cause it to break.
- You will need at least two people to install this unit properly.
- Seller is not responsible for any damage to the unit or personal property caused by improper installation.

## CARE AND CLEANING GUIDELINES

- For daily maintenance, use a wet cloth and a soft liquid cleaner.
- Never use abrasive cleaners or strong bleach, scrapers, metallic brushes, or other objects or any products which can graze or tarnish surfaces.

# PARTS:




|           |    |
|-----------|----|
| A         | ×5 |
| Ø8X38.5mm |    |



|         |    |
|---------|----|
| B       | ×5 |
| M4X40mm |    |



|   |    |
|---|----|
| C | ×3 |
|---|----|



|   |    |
|---|----|
| D | ×1 |
|---|----|




|   |    |
|---|----|
| E | ×1 |
|---|----|




|       |    |
|-------|----|
| F     | ×4 |
| Ø12mm |    |




|      |     |
|------|-----|
| G    | ×17 |
| Ø5mm |     |



|                |    |
|----------------|----|
| H              | ×8 |
| 20.1X10X17.2mm |    |



|       |    |
|-------|----|
| I     | ×1 |
| 220mm |    |



|      |    |
|------|----|
| J    | ×2 |
| 50mm |    |



|              |    |
|--------------|----|
| K            | ×2 |
| 758X458x70mm |    |

# TOOLS REQUIRD:



Pencil



Screw driver



Rubber mallet



Safety glasses




Drill and drill bit




Tape measure

# INSTALLATION




## 1.




**Option1:** If there is a socket on the wall, please put the plug into the socket.



**Option2:** If there is no socket on the wall, cut off the plug and connect the wires with wiring caps.




# 2.




Measure the height from the ground to the bottom plate and then install it with existing tools.


①





②




③




# 3.




# 4.




## ①





## ②





## ③




# 5.




# 6.



To adjust the vertical height.  
Loosen the four screws "N" on both hinges.  
Two of them are usually in slotted holes which  
allows you to adjust up or down by a fewmm.  
Then tighten back up.






To adjust depth.  
Loosen screw "B" and adjust door, if the door can  
not be adjusted, please loosen screw "C", then try  
again. Tighten screw "B" and "C".



To adjust side ways.  
Turning the screw "C" on both hing on each door.


# 7.

|                                                                                   |              |                                                                                     |             |
|-----------------------------------------------------------------------------------|--------------|-------------------------------------------------------------------------------------|-------------|
|  | <b>F</b> ×4  |  | <b>K</b> ×2 |
|  | <b>G</b> ×17 |  | <b>H</b> ×8 |




8.

**WARNING:**  
Maximum load: 1.4 kg (3 lbs)  
on each glass shelf.



**WARNING:**  
Maximum load: 4.5kg (10lbs)  
on bottom metal frame.



If a part is missing or damaged  
please feel free to contact us via custom service email  
**[furnitures.service@outlook.com](mailto:furnitures.service@outlook.com)**

We will gladly ships your replacement parts FREE of charge