



**ASSEMBLY INSTRUCTIONS**

1. FASTEN SOCKET ASSEMBLY (B) SECURELY ONTO BASE (A). BE CAREFUL NOT TO TWIST THE POWER CORD. TIGHTEN SECURELY.
2. PLACE HARP (C) ONTO SADDLE. PLACE SHADE (D) ONTO THE HARP (C).
3. TIGHTEN FINIAL (E).

**CLEANING**

DO NOT USE POLISH OR CLEANERS ON YOUR LAMP, JUST WIPE CLEAN WITH SOFT CLOTH.

**WARNING**

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

**DIRECTIVES D'ASSEMBLAGE**

1. BIEN FIXER LA DOUILLE (B) SUR LE BASE DE LAMPE AVEC USB (A). FAIRE ATTENTION DE NE PAS TORSIONNER LE CORDON D'ALIMENTATION. SERRER SÛREMENT.

**NETTOYAGE**

NE PAS POLIR NI UTILISER DE PRODUITS DE NETTOYAGE SUR LA LAMPES. SEULEMENT AVEC UN CHIFFON DOUX ET PROPRE.

**AVERTISSEMENT**

CETTE LAMPES PORTABLE A UN BOÎTIER EN PLASTIQUE ET UN CORDON D'ALIMENTATION POLARISÉ (UNE LAME EST PLUS LARGE QUE L'AUTRE). EN VUE DE RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, CE BOÎTIER NE PEUT ÊTRE INSÉRÉ DANS UNE PRISE POLARISÉE QUE D'UNE SEULE MANIÈRE. SI LE BOÎTIER NE PEUT ÊTRE INSÉRÉ, INVERSEZ LE. SI IL NE PEUT ÊTRE INSÉRÉ, CONTACTEZ UN ÉLECTRICIEN QUALIFIÉ. NE PAS UTILISER AVEC UN CORDON D'EXTENSION SAUF SI LE BOÎTIER PEUT ÊTRE INSÉRÉ COMPLÈTEMENT.