



ASSEMBLY INSTRUCTION




+ Parts Included


- ① SOFA BASE
1PC



- ② GOLD LEG
4PCS



- ③ MIDDLE LEG
1PC



+ Hardware Included

- A ALLEN WRENCH B BOLT

∅5/16 *60MM 1PC

M6*35MM 20PCS



- C WASHER

M6*16MM 20PCS



+ Do Not Use
Power Tools



+ Suggested
Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Sofa Base
- Part # - Gold Leg
- Part # - Middle Leg

Do not assemble if any of the following Hardware parts missing:


- Part # - Allen Wrench
- Part # - Bolt
- Part # - Washer

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

ASSEMBLY INSTRUCTION

1



2

