


Assembly Instructions


CAUTION : You must read this before you proceed

Please look in the magic tape pouch for hardware packs and legs

CHAISE LOUNGE



Parts List



Label	Picture	Description	QTY
A		Chaise Frame	1
B		Cushion	1
C		Pillow	1
D		Leg	4
E		Middle Leg	1

Hardware

Label	Picture	Description	QTY
①		Bolt(M8*50MM)	9
②		Flat Washer	9
③		Spring Washer	9
④		Allen Wrench	1
⑤		Plastic Washer	2

Assembly Preparation

Before
Beginning
Assembly:



X9



X1




X9



X2



X9



X4



X1



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

OVERVIEW




This Chaise Lounge has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chaise Lounge parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.

Step 1




Open the carton and place all the parts on a clean, non-marring surface. Remove the hardware package under the Cushion(B). Take out the Leg(D),Middle Leg(E) and hardware from the package as shown above.

Step 2




Position the Chaise Frame(A) on its back,open the non-woven fabric on the two sides the Chaise Frame(A).

Step 3



Install the Leg(D) onto the Chaise Frame(A) using Bolt(①) ,Spring Washer(③) ,Flat Washer (②) with Allen Wrench(④) turning clockwise until tight. Repeat the same step to install the remaining three legs.


Step 4



Install the Middle Leg(E) to Chaise Frame(A) by placing a Plastic Washer(⑤) onto the threaded stem of the Leg. Tighten by turning the Leg clockwise.


Note: The use of Plastic Washer(⑤) are OPTIONAL and are especially useful to help alleviate slight wobbles. Some Legs may need more than one Plastic Washer(⑤) whilst some Legs may not need any. Position Sofa right side up and test for stability on a Level Surface. Add or remove Plastic Washer(⑤) where needed to achieve stability.

Step 5



Turn the Chaise Frame(A) right side up, put the Cushion(B) on the Chaise Frame(A). Put the Pillow(C) on the Chaise Frame(A).

Step 6



Your Chaise Lounge is ready for use.
This Chaise Lounge can only be used on a flat, level surface.