



















Please read these instructions and warranty information carefully before use and keep them properly for future reference.


OPERATING INSTRUCTIONS

Part List


	Ax2		Px2
	Bx2		Qx4
	Cx2		Rx4
 M10*130MM	Dx4		x1
	Ex13		Tx1
	Fx11		
	Gx2		
 M10*190MM	Hx4		
 M10*85MM	Kx2		
 M10*80MM	Lx2		
	Mx4		
	Nx5		
	Ox4		

Assembly Instructions


①






②



③



Assembly Instructions



NOTE

1. Bolts for all the steps should not be tightened all the way until all bolts are fully put in, otherwise the holes will not line up. Once all in place then tighten bolts.
2. Diagrams showing bolts "D" and washers "E" for part "B" + "C". Tighten them well otherwise part "C" will crack if not secured.
3. Two or more people for assembly.