


INSTALLATION MANUAL

Ceiling Fan With Lights



Safety Rules

1. Be sure the power to the wires you are working on is disconnected, either the fuse is removed or the circuit breaker is turned off. Turning the power off using the light switch is not sufficient to prevent electrical shock.
2. A qualified licensed electrician is required for the installation.
3. The outlet box and support structure must be securely mounted and capable of reliably /supporting a minimum of 70 pounds. Use only UL (cUL for Canadian Installation) listed mounting boxes marked "FOR FAN SUPPORT".
4. The fan must be mounted with a minimum of 7 feet clearance from the trailing edge of the blades to the floor.
5. Do not operate reversing switch while fan blades are in motion (if applicable). The fan must be turned off and the blades stopped before reversing the blade direction.
6. Do not place any objects in the path of the blades.
7. To avoid personal injury or damage to the fan and other items, be cautious when working around or cleaning the fan.
8. Do not use water or detergents when cleaning the fan or fan blades. A dry dust cloth or lightly dampened soft cloth will be suitable for the cleaning.
9. After marking electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor on one side of the outlet box.
10. Electrical diagrams are reference only, different fan lights may have different light shades and bulbs.
11. Use only our replacement parts. This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and radiate radio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications.

Warning:

To reduce the risk of personal injury, use only the two steel screws and washers provided with the outlet box for mounting to the outlet box. Most outlet boxes commonly used for the support of lighting fixtures are not acceptable for fan support and need to be replaced, consult a qualified electrician if in doubt.

To reduce the risk of fire, electric shock, or personal injury, mount the fan to the outlet box marked "acceptable for fan support".


To reduce the risk of personal injury, do not bend the blade brackets (also referred to as flanges) during assembly or after installation. Do not insert objects in the path of the blades.

Installation Preparation


Tools You Need




☒ Ladder




☒ Pliers



☒ Wire Strippers



☒ Screwdrivers




☐ Power Drill (optional)




☐ Drill Bit (optional)

If mounting to a support structure, you will also need the optional tools.

What to Expect with Your Installation



☒ Must be able to secure the fan to building structure or fan-rated outlet box



☒ Assess location



☒ Check the box to see the weight of the fan




☒ Not applicable for angled ceiling

Switch Selection

Note: Using a dimmer switch to control the fan may damage the fan. To reduce the risk of fire or electrical shock, do not use a dimmer switch to control the fan.
The recommended switches are as follows:




Recommended:




Single Pole Switch
(Not Included)




Not Recommended:




Dimmer Switch



Timer Switch




Fan Speed Control
Switch



Motion Sensor
Switch


Installation Recommended

Room Size:





UP TO 12 ft × 14 ft

Room Height:



Recommended ceiling height: 7 to 12 ft.

Packing List



A Receiver × 1

B Mounting Bracket × 1

C Canopy × 1

D Fan Motor Assembly × 1

E Fan Blade × 5

F Light Kit × 1

G Light Shade × 1

Pre-assembled {

Installation Kit

AA	3x	BB	2x	CC	4x	DD	4x	EE	4x
									
Wire Nut		Outlet Box Screw		Wood Screw		Flat Washer		Anchor Bolt	
FF	3x	GG	1x	HH	1x	JJ	1x	KK	1x
									
Set Screw		Hook		Canopy Screw		Remote Control & Holder		Gloves	

- NOTE:
1. The listed quantity is for installation, extra hardware may be included.
 2. The mounting bracket (B) is pre-assembled on the canopy (C).


Installation Instructions

1. Assemble the Fan Blade

Step 1. Loosen the fan blade screw of the fan motor assembly (D).

Step 2. Align the fan blades (E) with the holes on the fan motor assembly (D), and secure them using the fan blade screws.


Note: Make sure to assemble the blades in sequence and fasten the screws with equal force.



2. Install the Light Kit


Step 1. Screw the light kit (F) onto the fan motor assembly (D).

Step 2. Connect the light wire terminal of fan motor assembly (D) to the interface on the light kit (F).




3. Remove Mounting Bracket

Rotating the mounting bracket (B) and take out from the canopy (C).



4. Hang the Hook


Hang the hook (GG) on the mounting bracket (B).



5. Mount the Bracket (3options)


Option 1. (For Outlet Box Structure)

Secure the mounting bracket onto the outlet box with box screws (BB) and washers (DD).








Option 2. (For Solid Wood Structure)

Mark and drill the screw holes on the solid wood structure. Mount the mounting bracket with wood screws (DD) and washers (CC).




Option 3. (For Concrete Structure)

Mount the mounting bracket to the concrete structure with anchor bolt (EE).




6. Assemble the Canopy

Step 1. Secure the canopy (C) to the fan motor assembly (D) with set screws (FF).




Step 2. Hang fan canopy (C) by hook (GG) on mounting bracket (B).




7. Connect the Wires

Step 1. Connect the fixture wires terminal to the interface on the receiver (A).

Step 2. Connect the wires from the receiver (A) to the house supply wires with wire nuts (AA) , ground wire (green, green/yellow, or bare copper) to ground wire, neutral wire (white) to neutral wire, and hot wire (black) to hot wire. Wrap the connection with electrical tape.




Step 3. Remove fan canopy (C) from hook (GG).




8. Complete Fan Assembly

Step 1. Rotate the canopy (C) to lock it onto the mounting bracket (B).


Step 2. Tighten the canopy screw (HH) to secure the canopy (C).



Step 3. Attach the light shade (G) to secure it to the light kit (F).



Install the Remote Holder




Remote Control Instructions

		Rotation the RGB.
		Turn on/off the RGB.
		Alternate the fan's rotation between forward and reverse.
		Turn off the fan.
		1/2/3/4/5/6 for fan speeds.
		Press to +/- the brightness of the light.
		Turn on/off the lights.
		Press to +/- the temperature of the light.
		1H/2H for timing the fan.
		Quick switch of the light color: Natural Light / White Light / Yellow Light
Note: Please insert 2 batteries before using. AAA 1.5V battery x 2pcs (not included). Remote Signal Pairing: If the remote control loses the signal of the fan, turn off the power from wall switch, then turn it on, press immediately for around 3 seconds, after the fixture beeps or flashes, then it's done.		

APP Control Instructions

Install the app from Google Play, Apple App Store, or other app stores by scanning the QR code on the product. Ensure that your phone is connected to the internet and Bluetooth is enabled.

		Pairing: Click the Pair button within 5 seconds after turning on the fan from the wall switch. Once the fan flashes or beeps, it has been successfully paired with your phone and can now be controlled through the app.
		Turn on/off the light.
		Quick switch for "White" light color.
		Quick switch for "Yellow" light color.
		Quick switch for "Natural" light color.
		Night mode: Dim the lights.
		Slide the slider to change the brightness of the light.
		Slide the slider to change the fan speed.
		Fan moves forward.
		Fan moves reversely.
		Change the direction of the wind. (Not supported)
		Timing the fan.
		Natural wind: The fan speed will change automatically when you use this function
		Sleeping wind. (Not supported)
		Turn on/off the fan.
		Unpairing: Click the unpair button within 5 seconds after turning on the fan. Once the fan flashes or beeps, it has been successfully unpaired from your phone.

Trouble Shooting

1. Fan doesn't work

- Check the remote control battery (not included in this package).
- Check the circuit breaker to ensure the power is on.
- Check the connection of the power cord.

2. Lights Do Not Light Up / Flicker / Noisy Operation

- Check the circuit breaker to ensure the power is on.
- Check the connection of the power cord.
- Check the connection of the LED light source.

3. Noisy Operation

- Re-tighten all screws on the bracket, and fan blades (do not over tighten)
- Check to see if the blade is cracked. If so, contact us to replace it

4. Remote does not work

- Make sure the battery is installed correctly.
- Pair the remote control again. (See "Remote Control Instructions")
- Install 2 new batteries.

Clean And Care

To clean, wipe the fixture with a soft cloth. Spraying from chemical cleaners can discolor the finish of the fixture. Do not use scouring pads, powders, steel wool, or abrasive paper to clean this fixture.

Ordering Parts

Keep this manual for future reference, and in case replacement parts are needed. Available parts can be ordered from the place of purchase. Use exact wording from diagrams when ordering parts.