


Column Monitor Mount

US PATENT NO. US11221102B2



CLMMMA2022

Installation Video




Need Help? Contact our pros:

647-557-5699

















WARNING STATEMENTS

Warning



Prior to the installation of this product, the installation instruction must be read and completely understood. Failure to do so may result in personal injury, property damage or voiding of manufacturer warranty.



Pay attention to the weight capacity of the mount. Exceeding the limitation can result in impairment or serious injury and property damage.




Never operate the mount if parts are missing or damaged.




Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaim any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.

PRODUCT LINE GRAPH




PARTS AND HARDWARE



STEP 1: ATTACH COLUMN MOUNTING BRACKET TO POST/COLUMN






Hold column mounting bracket to the column where you would like to mount the monitor


STEP 1: ATTACH COLUMN MOUNTING BRACKET TO POST/COLUMN






Ask a second person to wrap the strap around the column


STEP 1: ATTACH COLUMN MOUNTING BRACKET TO POST/COLUMN




STEP 1: ATTACH COLUMN MOUNTING BRACKET TO POST/COLUMN



4a. Bring the ratchet buckle snug to the column and pull the strap tight.




4b. Crank the handle to tighten the strap until it feels taut and secure.



- 4c. Close the buckle to lock it.
- 4d. Repeat steps a, b and c for the bottom strap.

STEP 1: ATTACH COLUMN MOUNTING BRACKET TO POST/COLUMN






Cut extra strap or fold and tuck away.

TO MAKE ADJUSTMENTS AFTER INSTALLATION

TV too high? Too low? Not centered? No problem! HOW TO ADJUST THE POSITION OF THE COLUMN MOUNTING BRACKET



A CAUTION:


Do not adjust the column mounting bracket while the TV is mounted

- a. To release the strap pull, and hold the lever towards the handle, then rotate the handle all the way to position C.
- b. Move your column mounting bracket to the new desired position and tighten.

Need Help? Contact our pros:


L 647-557-5699 ■ support@condomounts.com ⊕ condomounts.com

STEP 2: ATTACH ARM TO COLUMN BRACKET




extension arm.

STEP 2: ATTACH ARM TO COLUMN BRACKET



STEP 3: ATTACH MONITOR TO ARM


3.1





Attach adaptors if 200 x 200 VESA is required.

STEP 3: ATTACH MONITOR TO ARM




Flush Surface Installation: Install 4 screws through faceplate to monitor via mounting holes.

Recessed Surface Installation: Put 4 spacers between faceplate and monitor. Install 4 screws through faceplate, spacers to monitor via mounting holes.

STEP 3: ATTACH MONITOR TO ARM







Lift the VESA plate along with monitor and put it on head slot.


ADJUSTMENTS

GAS SPRING TENSION ADJUSTMENT





Be sure to keep the arm in horizontal position during adjustment. Or else, it would be difficult to adjust the mount.





1 turn ≈ 1 lbs ≈ 0.4kg

NOTE: Turn clockwise to reduce tension for lighter monitors and counter-clockwise to increase tension for heavier monitors.

Use a hex wrench to adjust the height tension of the gas spring arm after the monitors are installed, to keep different weight of monitors still at any position.

