


# ASSEMBLY INSTRUCTIONS










## HOPPER STUDIO


**APPROVED** 6/14/21

PRODUCT NAME : Sophia 3 Drawer Chest  
DIMENSIONS : 30"L x 19"W x 34"H  
ITEM NO. : 7185BK864BCY54  
7185LB303BCY54  
7185GY303BCY54  
7185BR303BCY54







1. Check for damaged or missing parts . Call 1-800-696-8446 to order missing supplies.
2. Use a soft surface or the carton as a working surface to prevent damage during assembly.
3. It is recommended to have 2 adults on hand for assembly.
4. Gather all tools prior to assembly.
5. **WARNING!** When included, anti-tipping hardware **MUST** be installed for your safety.


PARTS LIST:			QTY
A	Body Assembly		1pc
B	Side Leg		2pcs
C	Handle		3pcs
HARDWARE:			QTY
D	Flat Washer Ø5/16"		8pcs
E	Lock Washer Ø5/16"		8pcs
F	Hexagonal Nut Ø5/16"		8pcs
G	Wrench for Nut		1pc
H	Umbrella Head Machine Screw Ø5/32" x 3/4"		6pcs
I	Tipping Restraint		1set




# STEP 1



## STEP 2



## STEP 3



Note: The long screw included is suitable for most wall situations.

Use appropriate screw for your application. Do not overtighten the cable.

**WARNING! Anti-tipping hardware MUST be installed for your safety.**