
ASSEMBLY INSTRUCTION

Dinning Chair
XN24110



Component List

LABEL	PICTURE	DESCRIPTION	QTY
A		Seat	1
B		Left leg	1
C		Right leg	1
D		Cross stretcher	1


Hardware List


LABEL	PICTURE	DESCRIPTION	QTY
H1		Bolt:M6*30mm	2
H2		Bolt:M8*40mm	4
H3		Flat Washer	4
H4		Spring Washer	4
H5		Allen Wrench:M6	1
H6		Allen Wrench:M8	1

Assembly steps

1

H1 x 2pcs	H5 x 1pc
M6*30mm	M6







70% tightened

2


H2 x 4pcs	H3 x 4pcs	H4 x 4pcs	H6 x 1pc
M8X40mm	Flat Washer	Spring Washer	M8






70% tightened

3



Note: Each leg has an adjustable foot leveler to help level your chair.



Adjust the chair so that it is leveled , then fully tighten all the bolts.