


















Plow & Hearth

62A50 Product Name: X-BACK CHAISE LOUNGE

ASSEMBLY INSTRUCTION

1/1

	A- 2PCS
	B- 1PC
	C- 1PC
	D- 2PCS
	E- 2PCS
	F- 1PC
	G- 2PCS
	H- 1PC
	I- 1PC
	K- 1PC
	Washer(Ø25xØ40)-2PCS ①
	Washer(Ø6,5xØ30)-2PCS ②
	(M6 x 40)mm-8PCS ③
	(M6 x 20)mm-8PCS ④
	(M4 x 35)mm-2PCS ⑤
	(M8 x 40)mm-8PCS ⑥
	Allen Key -1PCS ⑦

