


ITEM NO. SBHD1693

Scan for manual,
video & advice.

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com


MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.


NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
30 minutes.



Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.

Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**


For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List

A ×1




Panel

B ×1




Left side panel

C ×1




Right side panel

D ×1




Baseplate

E ×1




Neutral board

F ×1




Back panel

G ×1




Leg

H ×2




Shelf board

I ×2




Middle door panel

J ×1



Right door panel


K ×1



Left door panel


Hardware List

1 ×4+1




Self-tapping screw
D4x20mm

2 ×24+2




Self-tapping screw
D3x16mm

3 ×8+1




Layer board support

4 ×4




Expansion pipe
L=30mm

5 ×4




Anti-tip component

6 ×2




Hardware pack

7 ×4+1




Self-tapping screw
D4x40mm

8 ×4+1




Self-tapping screw
D4x30mm

9 ×1




Hex wrench
M4

10 ×48+4




Self-tapping screw
D4x16mm

11 ×2




Door stopper

12 ×12+2




Wood plug
Ø8x30mm

13 ×4




Half-covered door hinge
Ø35 nn

14 ×4




Reinforced door hinge
Ø35 nn

15 ×8+1




Three in one
M6x35mm

16 ×8+1




Eccentric wheel

17 ×2+1




Direct repair screw
Ø6.3x50mm

18 ×4+1




Screw rod
M6x35mm

19 ×4




Iron sheet

20 ×4+1




Non-slip mat
30x15x3mm

21 ×4



Hold hands

22 ×1



Screwdriver

23 ×8+1



Self-tapping screw
D3x14mm

24 ×4+1





Pull screw
M4x25mm

ASSEMBLY INSTRUCTIONS

Step 01

Insert the three-in-one (15) into the corresponding holes on the left panel (B) and the right panel (C), and secure it with a screwdriver (22).


15		x 6	M6x35mm	22		x 1	Screwdriver



Step 02


1. Insert the three-in-one (15) into the corresponding hole on the panel (A), and secure it with a screwdriver (22).
2. Pass the self-tapping screws (8) through the door stopper wood (11) and insert them into the corresponding hole on the panel (A), then secure it with a screwdriver (22).


15	x 2	M6x35mm	22	x 1	Screwdriver
11	x 2	Door stopper	8	x 4	D4x30mm



Step 03

Insert the wooden dowel (12) into the corresponding holes of the panel (A) and the middle plate (E), install the eccentric wheel (16) into the corresponding hole of the middle plate (E), and secure it with a screwdriver (22).


16	 x 2	Eccentric wheel	22	 x 1	Screwdriver
12	 x 2	Ø8x30mm			



Step 04

1. Insert the wooden dowel (12) into the corresponding holes of the bottom plate (D) and the center plate (E).
2. Pass the straightening screws (17) through the bottom plate (D) and the center plate (E) to assemble them, and lock them with a hexagonal wrench (9).


17	 x 2	Ø6.3x50mm	12	 x 2	Ø8x30mm
9	 x 1	M4			



Step 05

1. Insert the wooden dowel (12) into the corresponding holes of the panel (A), the base plate (D), and the right side plate (C).
2. Insert the eccentric wheel (16) into the corresponding hole of the panel (A), and secure it with a screwdriver (22).
3. Assemble the screw (18) through the base plate (D) and the right side plate (C), and secure it with a hexagonal wrench (9).


16	x 3	Eccentric wheel	12	x 4	Ø8x30mm
18	x 2	M6x35mm	9	x 1	M4
22	x 1	Screwdriver			



Step 06

1. Insert the wooden dowel (12) into the corresponding holes of the panel (A), the base plate (D), and the left side plate (B).
2. Insert the eccentric wheel (16) into the corresponding hole of the panel (A), and secure it with a screwdriver (22).
3. Assemble the screw (18) through the base plate (D) and the left side plate (B), and secure it with a hexagonal wrench (9).


16	x 3	Eccentric wheel	12	x 4	Ø8x30mm
18	x 2	M6x35mm	9	x 1	M4
22	x 1	Screwdriver			



Step 07

Pass the self-tapping screws (23) through the iron sheet (19), the panel (A), the left panel (B), and the right panel (C) to assemble them together, and then secure them with a screwdriver (22).


23	x 8	D3x14mm	19	x 4	Iron sheet
22	x 1	Screwdriver			



Step 08

1. Insert the leg (G) into the corresponding hole on the base plate (D), and lock it in place in the direction indicated by the arrow.
2. Attach the anti-slip pad (20) to the corresponding positions on the left panel (B) and the right panel (C).


20	x 4	30x15x3mm




Step 09

1. Open the back panel (F), and then insert it into the back panel slot of the assembled cabinet.
2. Thread the self-tapping screws (2) through the back panel (F) and the cabinet to assemble them, and then tighten them with a screwdriver (22).

2	x 24	D3x16mm	22	x 1	Screwdriver



Step 10




Note:
Before the next step, adjust the feet of the locker to keep it level.

Step 11

Insert the shelf support (3) into the corresponding holes of the left panel (B), the center panel (E), and the right panel (C), and place the shelf (H) inside the cabinet.


3		x 8	Layer board support



Step 12

1. Insert the self-tapping screws (10) through the large curved door hinge (14) and the left door panel (K) to assemble them. Then, use a screwdriver (22) to lock them. Insert the self-tapping screws (10) through the large curved door hinge (14) and the right door panel (J) to assemble them, and then use a screwdriver (22) to lock them.
2. Insert the handle screws (24) through the left door panel (K) and the handle (21) to assemble them. Then, use a screwdriver (22) to lock them. Insert the handle screws (24) through the right door panel (J) and the handle (21) to assemble them, and then use a screwdriver (22) to lock them.


14	x 4	Ø35nn	10	x 8	D4x16mm
21	x 2	Hold hands	24	x 2	M4x25mm
22	x 1	Screwdriver			



Step 13

Insert the self-tapping screws (10) through the assembled left door panel (K) and the left side panel (B) to assemble them. Lock them in place with a screwdriver (22). Then insert the self-tapping screws (10) through the assembled right door panel (J) and the right side panel (C) to assemble them, and lock them with a screwdriver (22).


10	x 16	D4x16mm	22	x 1	Screwdriver



Step 14

1. Insert the self-tapping screws (10) through the middle curved door hinge (13) and the middle door panel (I) to assemble them, and then secure them with a screwdriver (22).
2. Insert the handle screws (24) through the middle door panel (I) and the handle (21) to assemble them, and then secure them with a screwdriver (22).


13	x 4	Ø35nn	10	x 8	D4x16mm
21	x 2	Hold dands	24	x 2	M4x25mm
22	x 1	Screwdriver			



Step 15


Pass the self-tapping screws (10) through the assembled middle door panel (I) and the middle support plate (E) to assemble them, and then lock them with a screwdriver (22).

10	x 16	D4x16mm	22	x 1	Screwdriver




Door Hinge Adjustment Instructions


Concealed hinges are three-way adjustable.




Horizontal by screw adjustment!




Concealed hinges are three-way adjustable.




In-and-out by loosening the hinge arm mounting screw or via cam adjustment!



Concealed hinges are three-way adjustable.



Vertical via slots in the mounting plate or via cam adjustment!




Scan for adj video

Step 16


Pass screw (1) through the anti-fall part (5) and insert it behind the panel, then tighten with screwdriver(22).


1	x 4	D4x20mm	22	x 1	Screwdriver
5	x 2	Anti-tip component			




Step 17


Install Anti-tip device (5) to the wall in this step.

7	 x 4	D4x40mm	5	 x 2	Anti-tip component
4	 x 4	L=30mm	22	 x 1	Screwdriver






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device 5 to the wall with screws 7.

Step 18

⚠WARNING




Children have died from furniture tipover.To reduce the risk of furniture tipover:

-ALWAYS install anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.



This is a permanent label.
Do not remove!

6	x 2	Hardware pack



WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)