


Regency Wine Rack Cabinet






Estimated time for assembly:

120 mins




Weight limitations are as follows:

Maximum Load
5 lb



Maximum Load
15 lb


Maximum Load
20 lb



Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damage.

For safety, please keep pets and children away from the assembly area.

Ensure the product is fully assembled before use. If you are missing any hardware or products, do not use it until you have restored the missing parts.



This furniture requires 2 people for assembly.

Read this instruction manual prior to assembly to familiarize yourself with the various steps.

Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.


Hand tight all hardware and careful not to over tighten to avoid damaging the product.

CAUTION

There are small components used in the construction of this product. Loose items should be kept away from pets and children to avoid a choking hazard.

Keep all plastic bags and packaging film away from pets and children to avoid suffocation.














PACKAGE CONTENTS



PACKAGE CONTENTS


CODE	DESCRIPTION	QTY
1	Top Panel	1
2	Center Panel	1
3	Base	1
4	Upper Left Lateral Panel	1
5	Upper Right Lateral Panel	1
6	Upper Medial Panel	2
7	Triangle Shelf Panel	4
8	Lower Left Lateral Panel	1
9	Lower Right Lateral Panel	1
10	Lower Medial Panel	2
11	Pentagon Shelf Panel	1
12	Vertical Decoration Strip	4
13	Left Striped Cabinet Door	1
14	Right Striped Cabinet Door	1
15	Left Cabinet Door	1
16	Right Cabinet Door	1
17	Wine Rack Left Panel	1
18	Wine Rack Right Panel	1
19	Wine Rack Top Panel	1
20	Wine Rack Center Panel	1
21	Wine Rack Bottom Panel	1
22	Wine Rack Back Panel	2

PACKAGE CONTENTS




Install all hardware perpendicular to the opening.


PACKAGE CONTENTS



2x



1x




1x



8x



2x



2x



2x




2x




2x



2x




40x + 4x





Install all hardware perpendicular to the opening.

Required tools for assembly (Not included)








1

Attach cam bolts to the wine rack left and right panels (17, 18).








2

Insert small wood dowels to the wine rack back panels (22).






3

Insert wood dowels to the wine rack top, center, and bottom panels (19, 20, 21).






4

Attach rotation pivot to the wine rack top panel (19).




5

Flip the wine rack top panel (19) up side down and attach wine glass racks to the bottom side of the panel.





6

Attach wine rack back panels (22) to the wine rack top and bottom panels (19, 21).







7

Attach the wine rack center panel (20) to the wine rack right panel (18).






8

Attach wine rack top panel (19) and bottom panel (21) to the wine rack right panel (18).





Insert guard rods (U) to the wine rack and assemble the wine rack left panel (17) to the assembly.





10

Attach the half circle guards to the wine rack.




11


Attach cam bolts to the center panel (2) and vertical decoration strips (12).



12




Insert wood dowels to the upper lateral panels (4, 5) and upper medial panels (6).



13







Assemble the upper lateral panels (4, 5) together.






14

Assemble the top panel (1) on top of the upper lateral panels (4, 5).






Attach triangle shelf panels (7) to the upper medial panels (6).




17

Assemble the upper medial panels (6) to the top panel (1).





18

Secure the triangle shelf panel (7) to the upper lateral panels (4,5).






19

Secure the upper medial panels (6) to the top panel (1).




20

Attach swivel plate to the center panel (2).





21

Insert the wine rack pivot into the top panel slot.





Make sure you have at least two people to put the top onto the base.



Note: Here you need a cushion to raise the bottom.



22

Assemble the center panel (2) to the other side of the upper shelf assembly.



23



Secure the swivel plate to the wine rack. Rotate the wine rack to gain access to the screw holes.



Secure four screws from this direction.

24

Rotate the middle wine rack 90 degrees, align it with the screw hole of the rotating plate, and install the screw.





Secure another four screws from this other direction.



Rotate the middle part by 90 degree to assemble.



25

Attach magnetic door catch to the center panel (2).





26

Insert pivot sockets to the center panel (2).





27

Attach cam bolts to the base (3).





28




Insert pivot sockets to the base (3).





Insert wood dowels to the lower lateral panels (8, 9) and lower medial panels (10).






Assemble decoration strips (12) to the lower medial panels (10).





Assemble the lower lateral panels (8, 9) together.







Attach the lower lateral panels (8, 9) onto the base (3).




Attach triangle shelf (7) to the lower medial panels (10).








Assemble the lower medial panels (10) onto the base (3).



Secure the triangle shelf panels (7) to the lower lateral panels (8, 9).




Assemble the upper shelf assembly on top of the lower shelf assembly.



Make sure you have at least two people to put the top onto the base.

37


Attach magnetic catch plates to the left and right cabinet doors (15, 16).



(O) 2x



(P) 2x



38

Attach pivot hinges to the bottom of the left and right cabinet doors (15, 16).




(H) 1x




(I) 1x



(K) 4x



Attach cabinet door handles (T) to the striped cabinet doors (13, 14).



40


Attach magnetic catch plates to the striped cabinet doors (13, 14).



(O) 2x




(P) 2x



41


Attach door hinges to the striped cabinet doors (13, 14).





(F) 4x







(G) 8x





Install striped cabinet doors (13, 14) to the cabinet.







When the clearance of the door is uneven, Adjust the cabinet door according to the figure.
If you still have trouble adjusting the door, please contact us.



Up and down
adjustment by
loosening the screws
on the mounting
plate.





Side to side
adjustment using
the front adjustment
screw on the hinge.








In and out
adjustment by
loosening the screws
on the hinge arm.

43



Insert shelf pegs into the cabinet and put pentagon shelf panel (11) onto the pegs.










Install cabinet door (15, 16) to the cabinet. Insert the bottom pivot hinge into the bottom socket first, then insert the top pivot hinge into the top socket and secure the cabinet door to the hinge.



Attach anti-tipping straps to the top of the cabinet.




Affix the cabinet to a wall.



Furniture must permanently fixed to the wall stud with included anti-tipping device to prevent the furniture from tipping over.

- Mark the drill position on the wall with a pencil.
- Drill a small hole on the marked position.
- Insert a wall anchor into the drilled hole.
- Fixed the anti-tipping strap to the wall with provided screws.


YOU'RE FINISHED!



Warning

Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with included anti-tipping device in order to prevent the furniture from tipping over.

Different wall materials requires different types of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact us or your local hardware store.



Warning

Only place items on top of the product if they meet the recommended size and weight limits.

Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and/or injuries.

Items placed onto this product must be resting on a support surface without hanging over the edges.

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of longevity, please follow the recommendations in this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months and tighten them if necessary.



CLEANING

- Clean the surface of the MDF (medium - density fiberboard) with a lightly dampened cloth.
- A small amount of mild soap can be used if necessary.
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF.

MDF will swell and distort when exposed to water damage. Make sure to dry the furniture immediately after cleaning.

⚠ WARNING

The manufacturer and seller are not responsible for any and all liability relating to personal injury, property damage or losses, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification or neglect of this product.

WARRANTY

Products come with a 1-year warranty from the date of delivery. **Register your product on our website to enjoy our limited lifetime warranty!**

AFTER-SALE SERVICE



Encounter any difficulties or missing parts?



Contact us



We will send you replacement.



Hassle free!
No need to worry about repackaging and sending your item back.