


Assembly Instructions



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings

- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.


Parts List (EN)




Parts List (EN)




It takes two people to work together to assemble the product.









Recommended to use a screwdriver to assemble the product





Do not use a hammer, it might damage the board.









The use of an electric wrench is not recommended. If used, please set the torque to the minimum.

①  1PC	②  2PCS	③  2PCS	④  4PCS
⑤  1PC	⑥  1PC		

Parts List (EN)



No. A Quantity: 22+2 Pcs Cam Lock Dowel 8*28mm 	No. B Quantity: 22+2 Pcs Cam φ15 	No. C Quantity: 10+1 Pcs Sticker Ø20 	No. D Quantity: 18+1 Pcs Dowel 8*30mm 
No. E Quantity: 4+1 Pcs Foot Pad Ø20 	No. F Quantity: 1 Pc Screwdriver 	No. G Quantity: 1 Pc Adjust The Foot 	

STEP 1




	A x 12 PCS
	B x 4 PCS
	D x 4 PCS

STEP 2




INSERTING AND TIGHTENING CAM-BOLT



Insert Cam-lock
with arrow align
to Cam-bolt head

CORRECT


WRONG



Align the arrow
on the Cam-lock
to the Cam-bolt
head and insert
the Cam-lock.
Ensure Cam-lock
is fully inserted.

	B×4PCS
	D×4PCS


STEP 3



INSERTING AND TIGHTENING CAM-BOLT



Insert Cam-lock
with arrow align
to Cam-bolt head




CORRECT



WRONG



Align the arrow
on the Cam-lock
to the Cam-bolt
head and insert
the Cam-lock.
Ensure Cam-lock
is fully inserted.




B×4PCS









D×4PCS

STEP 4





	E×4PCS
	G×1PC

STEP 5




	A×10PCS
	B×10PCS
	D×6PCS

STEP 6



STEP 7



Assembly complete