


OUTDOOR SWIVEL CHAIR SET ASSEMBLY INSTRUCTION



ATTENTION



Thanks for choosing our product.

- 1. Please check the part list carefully to make sure you've received all the parts.**
- 2. If there are any missing parts, please contact us with the number and quantity. We will send them to you ASAP.**
- 3. If there are any damaged parts, please contact us with clear pictures or video. We'll offer you the best solution after confirming it.**

NOTE

- 1. If one or some screws are fully tightened during assembly, the others screws may not be aligned with screw holes. 50% tighten before fastening all screws. Allen wrench is recommended instead of an electric drill.**
- 2. If some screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.**
- 3. If the items is not stable, please loosen all the screws, adjust it on a flat ground and tighten all the screws.**


Let Us Help You




Let Us Help You




- If you have any further questions, please feel free to contact us or through our official website. We will respond as soon as possible.
- Before beginning installation, please ensure you have all the necessary hardware, the serial numbers are correctly labeled and correspond to the list, and that the quantities are accurate.
- Enjoy your new purchase!




A*2 	B*4 	C*1 	D*2 
E*8  Bolt M6*15	F*20  Bolt M6*30	G*28  M6 flat washer	H*1 
I*1 	J*1 		


Step1




Step2



Step3



Step4



Step5

