Slumberdown®

BETTER SLEEP FOR EVERY BODY

ELECTRIC BLANKET

with 8 heat settings

Get the most from your Slumberdown Electric Blanket

CE UKCA

We know you can't wait to plug in your Slumberdown Electric Blanket. But give this booklet a quick read first.

It outlines some important information about safety, care and cleaning and at the back, you'll also find details of your Guarantee and our Customer Helpline. So it's probably a good idea to keep this booklet in a safe place, in case you need to refer back to it later.

Contents

Safety Instructions ..... **Page 3/4**

Read and follow these instructions carefully.

Fitting your Electric Blanket ..... **Page 4**

To get the best from your blanket, and to use it safely, you need to fit it properly.

Using your Electric Blanket ..... **Page 5**

Operating instructions for the hand control.

Cleaning and Care ..... **Page 6**

Instructions for washing, drying and caring for your blanket.

24-month Guarantee and Customer Helpline ..... **Page 7**

What to do in the unlikely event that your blanket is faulty.

Safety Instructions

Please keep these instructions somewhere safe, so you can refer back to them.

Your electric blanket should always be used as an underblanket. Here's some important information on how to use it safely.

Fitting your blanket

- Before fitting your electric blanket, please check and make sure that it is intact with no sign of damage. If in any doubt, do not use the blanket and contact the retailer that you purchased it from.
- Before connecting to the mains supply, make sure that the voltage and frequency indicated on the technical data of the appliance correspond to those of the mains supply. The rating is on the controller unit and care label.
- The appliance is only to be used with the controller and wire provided with this product.
- Don't tuck it under your mattress.
- Regular checks to be made if used with a mattress protector or topper to make sure that the electric blanket hasn't rucked or folded in use.
- Don't fit it on a sofa bed, inflatable bed or water bed.
- **Warning**! Do not use this product on an adjustable Bed as the Blanket and Mains Lead can get trapped in the hinges or mechanism!
- **Warning!** Never allow the mains lead to be stretched at the Plug or the Controller as this can result in serious damage to the wire!

Using your blanket

- Your electric blanket is designed to preheat indoor beds. Don't use it for anything else.
- **CAUTION!** For your comfort and safety, you should not leave your electric blanket switched on when you are in the bed.
- Don't use it outdoors, in hospitals or hotels.
- Babies or toddlers shouldn't use this blanket, so don't use it to heat their beds.
- Children under 8 should only use it if they're supervised by an adult.
- Children aged 8 years and above or people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this electric blanket if they're supervised or have been given clear instructions on how to use it safely. Children should always be supervised until they're mature enough to understand how to operate it safely and can be trusted never to play with it.
- This appliance can give rise to the risks of entanglement, strangulation, tripping or treading if not safely arranged. Keep cords out of the reach of young children and securely out of the way.
- It shouldn't be used by people who are insensitive to heat or by vulnerable people who can't react to overheating.
- Don't turn the blanket on if it's folded up or creased.
- It's best not to use a hot water bottle while using the electric blanket.
- Don't let the controls overheat and never cover the controllers.
- Only ever use the mains lead and the controls provided.

Safety Instructions (continued)

- DO NOT pull the power cable or blanket to remove the plug from the socket; remove by grasping and pulling the plug from the socket - do not pull on the power cable.
- DO NOT pull or lift the appliance by the power cable.
- When not in use, switch off the power and remove the plug from the Mains Socket.
- Do not leave the product unattended while connected to mains power supply or when in use.

Looking after your blanket

- Don't insert pins or sharp objects.
- Don't crease it, as it can damage the wiring.
- Make sure it's completely dry before turning it on. Never use it if it's wet.
- Allow it to cool down before you fold and store it.
- Rapid increases in temperature can be dangerous, so the overheat system should step in and cut off the power. If this happens, you won't be able to use the blanket.
- If your pet is prone to chewing, please do not leave the blanket unattended. We will not be liable to send a replacement in this event.


Disposing of your blanket


- Once the blanket has reached the end of its usable life, cut through the mains lead to make sure no one else can use it. Then take it to your local, council-run waste site. Please don't dispose of it in your normal domestic waste bin.

Fitting your Electric Blanket

1. Open the electric blanket out fully and lay it flat on the mattress, allowing space for pillows. If you use a mattress protector or topper, lay the electric blanket on the top of this.
2. Position the blanket so the mains lead is at the pillow end of the bed.
3. The blanket isn't as long as your mattress. So pull it down, so the area underneath your pillows isn't covered. See pic. A.
4. Pass the elasticated straps underneath your mattress to secure the blanket in place. See pic. A.
5. When the blanket is fitted securely, connect the mains lead to the electric blanket's socket. See pic. B.
6. Make sure the mains lead isn't too stretched by using an extension lead if you need one.
7. To detach the mains lead,just lift the flap on the blanket's socket and pull gently.
8. Cover the electric blanket with a fitted or flat sheet and you're ready to go!

It's a good idea to check your electric blanket regularly to make sure it's still fitting cosily and has no creases. Check the mains lead is still tight in the socket every now and again too.





Using your Electric Blanket


Before you turn your electric blanket on, check these 5 things:

1. The mains lead is uncovered, firmly connected to the electric blanket's socket and is not stretched in any way at the Plug socket or Controller.
2. Your electric blanket is fully unfolded.
3. Your electric blanket fits comfortably over your mattress, so creases can't easily appear. If you use a mattress protector or topper, lay the electric blanket on the top of this.
4. Your electric blanket is not tucked under the mattress.
5. Your electric blanket is covered with a fitted or flat sheet.

- All good? Great. Now plug it into a mains socket and preheat your bed using the following steps.
- To get it to just the right temperature, the hand control has 8 heat settings and 10 timer settings for body and feet.

1 to 8 = Low Heat to High Heat	1 to H = 1 Hour to 12 Hours

1. Press and hold the power button to turn on. The display will light up to indicate the blanket is switched on.
2. The Temp icon (Temp) will be illuminated. To adjust the temperature, lightly click the + or - buttons on the Body and Foot controls to reach your desired heat settings 1-8 (1 is the lowest, 8 is the highest).
3. To adjust the timer setting, firstly click the button. The Timer icon (Timer) will be illuminated. To adjust the timer, lightly click the + or - buttons on the Body and Foot controls to reach your desired timer settings.
4. Each click is 1hr and the display will indicate 1- H (1 = 1 hour, 9 = 9 hours, H = 12 hours).
5. To change between the Temp and Timer settings click the button Image.
6. Cover the bed with your blanket/duvet and the electric blanket will start warming your bed.
7. The blanket will automatically switch off after the selected time period.
8. To power back on go to Step 1.
9. To power off, hold and press the power button so no lights are illuminated/all lights are off.
10. If you do not unplug the blanket from the mains plug, when the blanket is powered on again it will remain at the previous heat and timer settings.



After pre-heating your bed, you should turn the controller off before getting into the bed.

IMPORTANT! Ensure Mains Cable is not bent, kinked, trapped or damaged during operation.

Cleaning and Care

Here are some hints that will help you get the best out of your electric blanket for years to come.

Storing your electric blanket

The safest place to leave your blanket during the warmer months is on your bed. But if you'd rather store it somewhere, allow it to cool down and then roll or loosely fold it up. Don't fold it too tightly or put heavy things on top of it, as it could damage the wiring.

Don't forget to remove the plug from the Mains socket when you are not using your blanket.

Washing the removable cover

The removable cover is designed to be removable for regular washing. Do not dry clean. Regularly washing the cover will help your blanket to stay in great shape for longer.

Simply unzip the removable layer and pop your blanket in the washing machine on a 40° gentle cycle. Pre-treat any stains by spot cleaning before placing in the washing machine.

Drying the removable cover

The removable cover can be tumbled dried on a cool/low setting.

Washing your electric blanket (the bottom layer with the heated wires)

Your Slumberdown electric blanket can be washed by hand or in the washing machine on a 40° gentle cycle. But never dry clean your blanket.

WARNING! Always disconnect the appliance from the mains socket and disconnect the mains lead/controller connector from the blanket's socket before washing. Make sure the controls don't get wet.

To hand wash

Fill a large bowl or a bath with warm water and mild washing powder or detergent. Leave the blanket to soak for 5 or so minutes, then gently wash. Rinse in clean water until the water runs clear. Once your blanket is clean, don't wring it out. Gently, but firmly, squeeze as much excess water out of the blanket as you can.

To machine wash

Pre-treat any stains by spot cleaning before placing in the washing machine. Pop your blanket in the washing machine on a 40° gentle cycle. Once your blanket is clean, don't wring it out. Gently, but firmly, squeeze any excess water out of your blanket. DO NOT make an additional spinning cycle in your washing machine.

Drying your electric blanket (the bottom layer with the heated wires)

The best place to dry your electric blanket is on the washing line. Gently reshape it while it's damp, then hang it up, being careful not to peg any wired areas. Make sure it's completely dry before you use it. DO NOT tumble dry. DO NOT iron.

Wear and tear checks

Make sure the plug, mains lead, electric blanket socket and controller remain undamaged, with no bare wire showing.

Make sure the wiring of your electric blanket isn't sticking out of the fabric anywhere.

Straighten out any wires that have looped or twisted back. Hold your electric blanket up to a window or light to check.

If there are signs of wear or damage or if the blanket doesn't work, provided it is within the 24 month warranty, please contact the Customer Helpline: info@slumberdown.co.uk

Pets

If your pet is prone to chewing, please do not leave the blanket unattended. We will not be liable to send a replacement in this event.

24-month Guarantee

- **If a fault develops within 28 days of purchase**, please accept our apologies and return it to the retailer you bought it from for a replacement. Don't forget to take your receipt along with you.
- **If a fault develops within 24 months of purchase**, please contact the Customer Care Helpline at the bottom of this page. They'll ask you for the information below, so it would be a good idea to fill in your blanket's details here. Hold on to your receipt too as proof of purchase.

Date of purchase.....

Place of purchase.....

Model Number.....

Controller Number.....

To register for your guarantee, please complete and submit the form via the QR code below or at: www.slumberdown.co.uk/new-registration.

The terms of our guarantee

- This electric blanket is designed for domestic/personal use only - this guarantee does not cover use in industrial/hospitality settings.
- Slumberdown will not be liable to replace the electric blanket if:
  - The user hasn't operated and cared for it in accordance with the instructions in this leaflet.
  - The fault is a result of misuse or negligence - whether accidental or deliberate.
  - The electric blanket has been used on the wrong power voltage supply.
  - The electric blanket has been tampered with by someone who isn't qualified.
- Slumberdown will not be liable for any indirect or consequential loss or damage as a result of a fault on your electric blanket unit.

This guarantee does not affect your statutory rights, and it does not give any additional rights other than those outlined.

Customer Care Helpline: info@slumberdown.co.uk

John Cotton Group Ltd,
Low Mill Lane,
Ravensthorpe,
West Yorkshire,
WF13 3LX

Scan to register your product guarantee

Slumberdown®

BETTER SLEEP FOR EVERY BODY

To view our full range visit slumberdown.co.uk