Assembly Instructions

Parts



1. Base × 1





2. Ball Track × 2

3. Track Cover × 2

4. Ball × 8

5. Partition × 4





6. Long Screw × 2

7. Short Screw × 1



8. Threaded Rod × 1

9. Cat Teaser Feather Toy



10. Round Platform



11. 4-Point Jester Hat Top







11.81 in (30 cm)

7.87 in (20 cm)

