


# ASSEMBLY INSTRUCTION



DE - MONTAGEANWEISUNG  
 FR - INSTRUCTIONS DE MONTAGE  
 DK - MONTAGEVEJLEDNING  
 CZ - NÁVOD K MONTÁŽI  
 ES - INSTRUCCIONES DE MONTAJE  
 FI - ASENNUSOHJE







HR - UPUTE ZA MONTAŽU  
 SE - MONTERINGSANVISNING  
 SI - NAVODILA ZA MONTAŽO  
 TR - MONTAJ TALIMATI  
 NO - MONTASJEANVISNING  
 IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ  
 NL - MONTAGE INSTRUCTIE  
 PT - INSTRUÇÕES DE MONTAGEM  
 PL - INSTRUKCJA MONTAŻU  
 HU - SZERELÉSI UTASÍTÁS



20 min



- ①  **x 8** HW-ST-01-078 (7 x 120)
- ②  **x 2** HW-ST-01-046 (7 x 90)
- ③  **x 3** HW-ST-01-043 (7 x 65)
- ④  **x 4** HW-ST-01-040 (7 x 50)
- ⑤  **x 4** HW-WD-17-011 (10x40)
- ⑥  **x 1** HW-ST-18-001 (4 x 98)

