


INSTRUCTIONMANUAL



Customer Service

Missing Parts:

If you find any parts missing from your product, please contact us immediately. We will respond within 24 hours and arrange to send you the missing parts as soon as possible.

Damaged Parts:

If any parts of your product are damaged upon arrival, please provide us with the specific part code(s) of the damaged item(s). Once we receive this information, we will promptly arrange for replacements to be sent to you.

Self-Purchased Parts:


If you have already purchased the missing or damaged parts on your own, please provide proof of payment, and we will process a partial refund for you.

We are committed to providing you with the best service to ensure a hassle-free experience.


Your satisfaction is our top priority!

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

**WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE**




CAM-LOCK



Quickfit head needs to be in centre


QUICKFIT

Tighten until shoulder is flush with panel. DO not overtighten or undertighten (see example below)




BOARD IDENTIFICATION

1




1 PC

2



1 PC

3



1 PC

4



1 PC

5



1 PC

6




1 PC

7




1 PC

8




1 PC

9



1 PC


10



1 PC


BOARD IDENTIFICATION

11




2 PCS

12




2 PCS

13




1 PC

14




2 PCS

15




2 PC

16




2 PCS

17




2 PCS

18



2 PCS


19



2 PCS


PART LIST

A




42+2 PCS

B



42+2 PCS


C



8*30MM

32+2 PCS


D



4*35MM

12+1 PCS


E



3.5*12MM


20+2 PCS

F



2 PCS


G



4*12MM


2 PCS

H




2 PCS

I



4 PCS


J



3*16MM


4 pcs

K




4 PCS

L




2 PCS

CL




2 PCS

CR




2 PCS

DL





2 PCS

DR









2 PCS

BOARD IDENTIFICATION





STEP 1




A		16pcs
G		2pcs
H		2pcs

STEP 2




B		12pcs
C		12pcs

STEP 3




STEP 4





A		4pcs
B		4pcs
C		4pcs

STEP 5




B		12pcs
C		12pcs


STEP 6




B		4pcs
C		4pcs

STEP 7



A		10pcs
D		10pcs




STEP 8



x 2



B		10pcs
E		12pcs
F		2pcs
DL		2pcs
DR		2pcs

STEP 9



D		2pcs
K		4pcs
J		4pcs
L		2pcs

STEP 10



CONTACT US !

Do Not return this product

Contact our friendly customer service team first for help.

If you find that any accessories are missing from your product, please contact us immediately. We will respond within 24 hours and arrange to send you the missing parts as soon as possible.

If you have already purchased the missing accessories on your own, please provide proof of payment, and we will process a partial refund for you.

For any other questions or concerns, feel free to reach out to us. We are committed to ensuring that you experience no inconvenience or loss.