
Walnest Parrot Cage



Thank you for shopping from us!

In order to enable you to better install or use this product, please carefully read the precautions and detailed functional operation instructions mentioned in this manual before using this product formally.

Hope you will have a good experience!






Assembly Guide

This assembly guide includes the Part List, Installation Steps and Warning Tips













The item may be shipped into shipped in two boxes to facilitate transportation, and please understand that sometimes the packages may not arrive at the same time. Please check your package once you receive it.

⚠ It takes several people to assemble the cage together. Do not tighten the screws until the assembly is complete


Part list 1 ▼

Ⓐ ×3 	Ⓑ ×2 	Ⓔ ×1 
Ⓗ ×2 	Ⓘ ×5 	Ⓙ ×10 

Part list 2 ▼

Ⓒ ×3 	Ⓕ ×2 	Ⓓ ×1 
Ⓖ ×2 	Ⓗ ×2 	Ⓚ ×8 
Ⓛ ×2 	M1 ×115 	M2 ×95 
Ⓝ ×2  Hex wrench	Ⓞ ×8 	Ⓟ ×1 
Ⓠ ×2 		Ⓡ ×2 


Exploded view



Installation Steps

Step1


- Install the lower pieces first
- Adjustable feet should placed at the end of this step for installation
- A minimum of two people is required for installation



Installation Steps

Step2


- Install the 6 pieces of the middle layer one by one.




Installation Steps


Step3


Install the top 6 pieces with the order shown on the right.
Two people are necessary






Only 4 screws are needed here








Tip:
This may not be the only way to install it

Step4


Place the result of step 3 on top of the result of step 1.



Installation Steps

Step5


- Tighten the remaining screws and nuts
- Don't forget to install the connecting tab between **D** and **E**



Installation Steps


Step6

- Hang **Q&P** to the top of the cage from inside.




Installation Steps

Step7






Install exploded view



Tip:
This may not be the only place to install it

Installation Steps

Finish!



Security/ Notice

• Fasten screws loosely during initial assembly. Do not firmly tighten the screws until the item is completely assembled.
• Be aware that some parts are heavy and have sharp edges.
• If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
• Reconfirm that all bolts, screws, and knobs are secure every 90 days.
• Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

Warranty Guidelines

• If this product or any associated parts are found to be defective or missing at the time of receipt, Walnest will repair or replace, at its option, the defective parts at no charge.

to the original purchaser. Replacement parts or repaired parts shall be covered for the remainder of the Original Limited Warranty Period. All shipping costs will be the responsibility of the seller.
• Continuous free technical support is provided, including online diagnosis and trouble-shooting to users' problems, and come up with solutions in time. In order to process your claim, please upload a copy of your receipt along with AT LEAST 2 photos of the issue/damaged parts. Otherwise, supplier reserves the right to refuse replacement parts or credit.
• If a warranty claim is made after 30 days after purchase for missing or defective parts, the consumer is responsible for costs of parts and shipping.

What is not covered by this limited warranty?
• Item past the warranty.
• Products that has been subjected to abuse, overweight, accident, alteration, modification, tampering, vandalism, negligence, misuse, abrasive contact, faulty installation or lack of reasonable care.

• Damage to the contents of products, any person or property is excluded. Normal and foreseeable service wear or tear.
• Parts damaged due to improper installation or assembly.
• Damage that occurs due to acts of nature, i.e. hurricane, tornado, wind, flood, snow, wind driven debris, etc.
• Third party labor or installation fees of any kind are not recoverable under the warranty.
• Other circumstances stipulated by law.

Return Policy

Return is available if you are unsatisfied with the product or bought the wrong item within 1 month of receiving item. Please contact us via platform message, and we will send you the free prepaid return label.

The item should be returned in original unused condition and in the original packaging. Refunds typically take 2 business days after we have received and inspected your returned order. Please NOTE, the refund might be partial deducted in the following cases:
1. The returned item condition is different with reported;
2. Parts used or missing of returned item;
3. Buyer remorse purchase return, such as item no longer needed, wrong color/ size purchased, doesn't fit or like.
The Return Policy may not apply in all cases, depending on factors such as condition of the product, where the product was purchased, or whom you purchased the product from. Please email the purchase platform if you have any questions.