


Assembly Instructions

LB-4MHLCBG



BEFORE STARTING

Before Using Product

Read each step carefully before starting. It is very important that each step is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.

Make sure all parts are included.

Work in a spacious area and near where the unit will be used, preferably on a carpet, or use a piece of the cardboard packaging to protect your floor and product.

For a smooth assembly process, we suggest you keep a lite tightness for all the screws during assembly. After the whole product is assembled, firmly tighten all the screws.

WARNING

Do not allow children to climb on unit.

Avoid sharp objects or corrosive chemicals to prevent damage to the product.

During assembly, keep parts and packaging materials away from children and pets as there could be potential injury and choking hazards.

Please make sure that all objects are removed before moving the assembled unit.

The unit must be team lifted, not dragged or pushed. Failure to do so could cause instability, product collapse, and/or serious injury.

Be careful when using power tools to assemble your furniture.


Power tools may strip or damage the parts.

Adjusting the doors / Réglage des portes / Ajuste de las puertas


IMPORTANT — The furniture **MUST** be level on a flat, solid floor surface for the doors to work properly. Remove all items from furniture, then turn the leveling feet under the cabinet to make sure the furniture is level. Once the furniture is level, align the doors as shown for proper operation.

IMPORTANT — Le meuble **DOIT** être de niveau sur une surface de sol plane et solide pour que les portes fonctionnent correctement. Retirez tous les éléments des meubles, puis tournez les pieds de nivellement sous l'armoire pour vous assurer que le meuble est de niveau. Une fois le meuble de niveau, alignez les portes comme indiqué pour un bon fonctionnement.

IMPORTANTE — El mueble **DEBE** estar nivelado sobre una superficie plana y sólida para que las puertas funcionen correctamente. Retire todos los artículos de los muebles, luego gire las patas niveladoras debajo del gabinete para asegurarse de que esté nivelado. Una vez que el gabinete esté nivelado, alinee las puertas como se muestra para una operación adecuada.



FRONT VIEW | VUE DE FACE | VISTA FRONTAL



UP AND DOWN


Use screws to adjust the gaps at the top and bottom of door.

HAUT ET BAS


Utilisez des vis pour ajuster les espaces en haut et en bas de la porte.

ARRIBA Y ABAJO

Use tornillos para ajustar los espacios en la parte superior e inferior de la puerta.



FRONT VIEW | VUE DE FACE | VISTA FRONTAL



LEFT AND RIGHT


Use screw to adjust the gaps at left and right of the door.

GAUCHE ET DROITE


Utilisez la vis pour ajuster les écarts à gauche et à droite de la porte.

IZQUIERDA Y DERECHA

Use un tornillo para ajustar los espacios a la izquierda y a la derecha de la puerta.



TOP VIEW | VUE DE HAUT | VISTA SUPERIOR



IN AND OUT


Use screw to move the door in or out.

DEDANS ET DEHORS


Utilisez la vis pour déplacer la porte vers l'intérieur ou vers l'extérieur.

DENTRO Y FUERA
















Use un tornillo para mover la puerta hacia adentro o hacia afuera.








PART LIST














PART LIST

①  1 pc	②  1 pc	③  1 pc
④  1 pc	⑤  2 pcs	⑥  2 pcs
⑦  4 pcs	⑧  2 pcs	⑨  1 pc
⑩  2 pcs	⑪  1 pc	⑫  1 pc
⑬  1 pc	⑭  1 pc	⑮  4 pcs
⑯  2 pcs	⑰  1 pc	⑱  2 pcs




PART LIST

19  2 pcs	20  2 pcs	21  2 pcs
22  2 pcs	23  1 pc	

HARDWARE LIST

A X24+1  Ø8X30MM	B X26+2  Ø5X40MM	C X26+2  Ø15X10MM
D X20+1  Ø3X12MM	E X20+1  Ø4X35MM	F X2 
G X12 	H X4 	I X8+1  Ø4X50MM
K X2 	L X4 	M X8 
O X8+1  Ø5X16MM	P X48+2  Ø3.5X14MM	Q X1 
R X2 	X1 	




STEP 1





Warning: Ensure proper alignment and direction when installing the product's slide rails, paying close attention to left and right orientation. Failure to do so may result in damage or loss.

D		X6
F		X1


STEP 2



Warning: Ensure proper alignment and direction when installing the product's slide rails, paying close attention to left and right orientation. Failure to do so may result in damage or loss.



B		X6
D		X6
F		X1

STEP 3



A		X2
B		X2
I		X2
R		X2


STEP 4




7

A		X2
B		X1
C		X2


STEP 5




STEP 6



STEP 7




STEP 8



STEP 9

The back panel ⑥ is folded in half.
Unfold it before installing it.




STEP 10


E



X4



STEP 11



A



X6

I




X6

STEP 12

Q




X1




Adjust the height of the screw teeth on the feet appropriately to ensure the product remains perfectly level and more fit the ground.



Instructions for use: The cabinet legs should be designed to avoid lateral stress. When moving, please lift vertically off the ground. Dragging may cause loose connectors, affecting stability and service life

STEP 13





STEP 14



B		X6
E		X4
K		X2

STEP 15




A		X6
C		X6


STEP 16

Please be sure to install the mending wedges to prevent the product from becoming unstable or wobbling.

CAUTION



Install and tighten backplate screws to ensure stability




G






X12

STEP 17



Drilling hole



WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!




K




X2


STEP 18



X2





STEP 19



X2


STEP 20




X2




STEP 21



X2



STEP 22




DL

!CAUTION

① Hole position sequence

② Left-right orientation.





DR

!CAUTION


① Hole position sequence

② Left-right orientation.




D		X8
F		X2

STEP 23




STEP 24



X4

P		X16
M		X8

STEP 25



P		X32
L		X4

STEP 26

