

Thank you for purchasing a Comfort Glow portable comfort furnace. For your safety and to insure that you get the full benefit of this powerful heater please take the time to read this guide completely BEFORE using your heater.

Table of contents, Specifications, Safety features	2
Important Safety Instruction	3
What to expect, Results, Suggestions and Helpful Hints	4
Operation, Maintenance	5-9
Troubleshooting	9- 10
Warranty Guidelines	11-12

SPECIFICATIONS

Features:

- Quartz Heatig Tubes
- Remote Control
- High & Low Heat Settings
- Timer
- Cool Touch
- Easy Roll Casters
- 1 Year Warranty

Electrical:

- Voltage 120V 60Hz
- Power Consumption:
High: 1500w Low: 750w
(+5% - 10% tolerance)

SAFETY FEATURES

Tip-Over Safety Feature

This heater is equipped with a tip-over safety feature. Once the heater is tipped over, an internal switch will automatically shut the heater off. Once the heater is restored an upright position, the heater will reset. To continue operation, turn on the heater using the supplied remote control or the control panel on the heater.

Overheat Safety Feature

This heater is equipped with a overheat safety feature. When the heaters internal components reach a certain temperature that could cause overheat and possible fire, the heater will automatically shut off.