User Manual

Welcome

Thanks for purchasing this **Christmas Tree Urn Filler**, Please read this user manual carefully before use.

Package List

Upon opening the package, please check for the following items:

* 2 × Christmas Tree Urn Filler
* 1 × User Manual
* 2 × Tripod Stake

Specifications

* Product Type: Lighted Christmas Tree Urn Filler
* Color: Green
* Material: PVC, Iron Frame, LED String
* Powered By: 3Pcs AA Batteries(Not Included)
* Per Tree Bead Quantity: 50Pcs
* Timer: Auto On 6 Hours, Off 18Hours
* Waterproof Rating: IP44
* Lead Cable Length: 33cm/13in
* Base Frame Size: 16×16×16cm/6.3×6.3×6.3in
* Per Item Size: 50×50×60cm/19.7×19.7×23.62in
* Per Item Weight: 1.3kg/2.86lbs

Highlights

* Features meticulously detailed foliage, rich green pine branches, natural-looking pine cones, and vibrant red berries. Its realistic appearance adds an artistic touch to any room, effortlessly creating a warm and festive holiday atmosphere.
* Powered by 50 warm LED beads, allowing you to enjoy 8 distinct lighting modes freely, easily creating a cozy and romantic mood for the season.
* After being activated, the tree will auto glow beautifully for 6 hours and then shut off for 18, cycling daily to save energy.
* Operation could not be simpler: just insert 3 AA batteries (not included) and use the one-button control to cycle through your favorite lighting effects.
* With an IP44 waterproof rating, this tree is built to shine in any setting, indoors or out. Perfect for porches, patios, gardens, planters, or lawns to spread festive cheer throughout your holiday celebrations.

Lighting Modes

1. Combination
2. In Wave
3. Sequential
4. Sló Glo
5. Chasing/Flash
6. Slow Fade
7. Twinkle/Flash
8. Steady On
9. Off


Easy Operation



* Insert 3Pcs AA batteries (not included) to power.
* Short press the power button to turn on, press again to switch 8 lighting modes and turn off.
* When switch on the light (no matter what lighting modes), the timer will be activated automatically: the light will brighten up 6 hours then auto turn off 18 hours.

Installation Guide

1. Place it in the pot (Pot not included)



Step1 Step2

2. Insert it on the ground



Step1 Step2 Step3

Safety Warning

Before using this product, please read the entire manual, paying particular attention to the safety instructions. Failure to follow these instructions may result in damage to the product.

Electrical Safety

* Do not use this product near water or in damp conditions.
* Ensure that the power supply is disconnected before attempting any maintenance or cleaning.

Child Safety

This product may contain small parts that could pose a choking hazard to children. Adult supervision is required during use.

Maintenance and Cleaning

To maintain the appearance and longevity of your Christmas tree lights, follow these guidelines for cleaning and maintenance.

* Always remove the batteries before cleaning
* Use a soft, dry cloth to gently wipe the lights. Do not use any harsh chemicals or abrasive materials.
* If necessary, dampen the cloth with water and mild detergent.
* Allow the lights to dry completely before power on.

Foreseeable Risk Warning for Dry Cell Batteries



1. Risk of Chemical Burns:

Hazard: Dry cell batteries contain corrosive chemicals that can cause burns if the battery leaks or ruptures.
Precaution: Handle damaged or leaking batteries with care. Wear protective gloves and avoid contact with skin or eyes. In case of exposure, rinse thoroughly with water and seek medical attention.



2. Risk of Ingestion (for small batteries):

Hazard: Small dry cell batteries, such as button cells, can be swallowed, especially by children. Ingestion can lead to severe internal burns, tissue damage, or death.
Precaution: Keep dry cell batteries out of reach of children. Ensure battery compartments in devices are securely closed and require a tool to open.



3. Choking Hazard (for small batteries):

Hazard: Small dry cell batteries pose a choking risk, particularly for young children.
Precaution: Do not allow children to handle dry cell batteries. Store batteries in a secure location away from children.



4. Risk of Fire or Explosion:

Hazard: Dry cell batteries can overheat, catch fire, or explode if short-circuited, overcharged, or exposed to high temperatures.
Precaution: Avoid exposing batteries to extreme heat, direct sunlight, or physical damage. Use only compatible chargers and follow manufacturer instructions for charging.



5. Environmental Hazard:

Hazard: Improper disposal of dry cell batteries can lead to environmental contamination due to the toxic materials they contain.
Precaution: Dispose of used dry cell batteries in accordance with local regulations. Recycle batteries at designated collection points to prevent environmental harm.



6. Legal Compliance:

Note: This warning is provided in compliance with U.S. consumer protection laws and regulations, including the Consumer Product Safety Improvement Act (CPSIA) and other relevant statutes.



Emergency Response:

-- If a dry cell battery leaks, overheats, or catches fire, move it to a safe, non-flammable area if possible. Use a Class D fire extinguisher or sand to extinguish the fire. Do not use water. Seek immediate medical attention for any injuries or exposure.
-- This warning is intended to inform consumers of the potential risks associated with dry cell batteries and to promote safe handling, use, and disposal practices.



Disposal

-- Do not discard with household waste.
-- Return to designated collection points (e.g., recycling centers or retail drop-off bins).
-- Tape terminals before disposal to prevent short-circuits.
-- Comply with local regulations for battery recycling.