


Sling Chair










ASSEMBLY MANUAL




- Prior to assembly, please confirm all of the parts listed included.
- All bolts should be tightened before use. Maybe, you need allen wrench for assembly.

Missing part? Damaged? Contact us via email at
service@domioutdoorliving.com

www.domioutdoorliving.com


				
A	B	C	D	E
1PC	1PC	1PC	1PC	M6*25 2PCS
				
F	G	H	I	
M6*18 8PCS	D6 10PCS	1PC	S4 1PC	

⚠ Please don't tighten the screws until the last step.




Assembly armrest (Part A) with the seat (Part C) according to the direction of the picture. Then put on the Part G and Screws (Part F).

A




B

Assembly back (Part D) with the seat (Part C) according to the direction of the picture. Then put on the Part G and Screws (Part F); Put on the Part G and Screws (Part E).



C

Assemble armrest (Part B) and the seat (Part C) according to the direction of the picture. Then put on the Part G and Screw (Part F). Assemble armrest (Part B) and the back (Part D) with Part G and the Screws (Part E).



Put on the cushions(Part H).

D