





ASSEMBLY INSTRUCTIONS

Ax1	 Seat
Bx2	 Front leg
Cx2	 Rear leg
Dx4	 Adjuster cap
Ex4	M8*60mm  Screw
Fx4	M8*50mm  Screw
Gx8	M8  Spring washer
Hx8	M8*22mm  Flat washer
Ix1	M8  Allen key

① The legs are hidden under the seat frame





Put the front leg in the dotted box place, Reach to the bottom and tighten the screws.


Tighten all the screws to 80% of maximum tightness

WARNING:
DO NOT STAND ON THE PRODUCT, DO NOT USE THIS PRODUCT AS A STEP LADDER.
DO NOT USE THIS PRODUCT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.
PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR PRODUCT.

②








Tighten all the screws to 80% of maximum tightness


③



Close the zipper of bottom Non-Woven fabric.

Tighten all the screws to
100% of maximum tightness

④



There are 4 small adjusters on the legs ,ensure these are adjusted so the chair sits level